



13

ACHTUNG !!!	!	CAUTION !!!
Zum Anlernen des EWS-Steuergeräts sind zwei schwarze Zündschlüssel erforderlich.		To program the ICU control unit, the two black ignition keys are required.

Pos	Part Number	Description	Additional Text	Quantity
1	62014010050	COVER COCKPIT SUPPORT		1.00
2	62014010100	COCKPIT SUPPORT		1.00
3	62014010060	ADJUSTING KNURL COCKP. SUPPORT		1.00
4	69008021080	clip nut M5		6.00
5	58214069051	rubber grommet 16x10.8x3		3.00
7*	0081645121	EJOT DELTA PT SCREW 45X12-Z		3.00
9	62114069100	SPEEDOMETER	ONLY FOR JAPAN	0.00
9	62114069000	SPEEDOMETER KM/H		1.00
12	62011066000	IGNITION LOCK		1.00
13	62611021000	IMMOBILIZER 990SM W. MASTERKEY		1.00
14	58407008300	TANK PLUG		1.00

15	62607050000	SEAT LOCK		1.00
16	62611067000	KEY WITH TRANSPONDER		0.00
17	62011066044	LOCK SET		1.00
18	60011064000	TAMPERPROOF SCREW F. IGN. LOCK		2.00
19	0035080206S	SHCS M8x20 TX45		4.00
20	0081050181	SCREW FOR PLASTIC K50X18 T20	300 TPI Erzbergrodeo	2.00
21	60211022000	HAZARD WARNING BUTTON		1.00
22	60111042100	SOCKET		1.00
23	62111042060	CABLE FOR SOCKET SMT		1.00
25	60011093075	RUBBER CABLE TIE 75MM 03		1.00

* = New part