



**ACHTUNG !!!**

Zum Anlernen des  
EWS-Steuergeräts  
sind ein roter und  
mindestens ein schwarzer  
Zündschlüssel erforderlich.

**CAUTION !!!**

To program the  
ICU control unit,  
one red and at least one  
black ignition keys  
are required.

Pos	Part Number	Description	Additional Text	Quantity
-----	-------------	-------------	-----------------	----------

1	69014069200	SPEEDOMETER		1.00
2	69014078000	RUBBER SLEEVE 10X14X20 08		2.00
3	69014012000	COVER IGNITION LOCK 08		1.00
4	61014068100	SPEEDOMETER SENSOR 10		1.00
5	0084040083	CYL.HEAD SCREW DIN0084-M 4X8 A		2.00
6	60111094000	CLIP 5/7 MM 06		3.00
10	69011066044	LOCK KIT RC8 08		1.00
11	61111064000	TAMPER-PROOF SCREW 07		2.00
12	69011066100	STARTER LOCK RACELOCK W. ANT.		1.00
13	69011021000	IMMOBILIZER WITH MASTERKEY		1.00
14	69007008000	TANK CAP		1.00
15	69007050000	SEAT LOCK		1.00
16	60411067000	KTM ignition key		1.00