



<b>ACHTUNG !!!</b>	<b>!</b>	<b>CAUTION !!!</b>
Zum Anlernen des EWS-Steuergeräts sind ein roter und mindestens ein schwarzer Zündschlüssel erforderlich.		To program the ICU control unit, one red and at least one black ignition keys are required.

Pos	Part Number	Description	Additional Text	Quantity
1	62014010050	COVER COCKPIT SUPPORT		1.00
2	62014010000	COCKPIT SUPPORT		1.00
3	62014010060	ADJUSTING KNURL COCKP. SUPPORT		1.00
4	69008021080	clip nut M5		6.00
5	58214069051	rubber grommet 16x10.8x3		3.00
6	0021050003	washer DIN 9021 A - 5.3		3.00

7	0081050121	EJOT PT screw K50x12	only for US and SixDays	3.00
9	61114069100	SPEEDOMETER 07		1.00
10	62514068100	SPEEDOMETER SENSOR 06		1.00
11	0084040083	CYL.HEAD SCREW DIN0084-M 4X8 A		2.00
12	62011066000	IGNITION LOCK		1.00
13	62611021000	IMMOBILIZER 990SM W. MASTERKEY		1.00
14	58407008300	TANK PLUG		1.00
15	62607050000	SEAT LOCK		1.00
16	62611067000	KEY WITH TRANSPONDER		1.00
17	62011066044	LOCK SET		1.00
18	60011064000	TAMPERPROOF SCREW F. IGN. LOCK		2.00
19	0035080206S	SHCS M8x20 TX45		4.00
20	0081050181	SCREW FOR PLASTIC K50X18 T20	300 TPI Erzbergrodeo	2.00