



ACHTUNG !!!

Zum Anlernen des EWS-Steuergeräts sind ein roter und mindestens ein schwarzer Zündschlüssel erforderlich.

CAUTION !!!

!

To program the ICU control unit, one red and at least one black ignition keys are required.

Pos	Part Number	Description	Additional Text	Quantity
-----	-------------	-------------	-----------------	----------

1	69014069200	SPEEDOMETER		1.00
2	69014078000	RUBBER SLEEVE 10X14X20 08		2.00
3	69014012000	COVER IGNITION LOCK 08		1.00
4	61014068100	SPEEDOMETER SENSOR 10		1.00
5	0084040083	CYL.HEAD SCREW DIN0084-M 4X8 A		2.00
6	60111094000	CLIP 5/7 MM 06		3.00
7*	69101085000	SPEEDOMETER CABEL FIXING RC8		1.00
10*	69011066244	LOCK SET RC8		1.00
11*	0025080306S	HH COLLAR SCREW M8X30 TX40		2.00
12	69011066100	STARTER LOCK RACELOCK W. ANT.		1.00
13	69011021000	IMMOBILIZER WITH MASTERKEY		1.00
14*	69007008100	TANK CAP		1.00
15	69007050000	SEAT LOCK		1.00
16	60411067000	KTM ignition key		1.00

* = New part