



Pos	Part Number	Description	Additional Text	Quantity
1	6031010114430	REAR WHEEL CPL. 5,0X17"		1.00
2	6031001004433	REAR HUB CPL. BLACK		1.00
3	60010011000	Bearing spacing tube L=124.8mm		1.00
4	0625062052	Grooved ball bear. 6205-2RSHC3		2.00
5	0472052200	CIRCLIP DIN0472-52X2		1.00
6	0760305271	Radial shaft seal 30X52X7		1.00
7	60310013000	SPACER BUSHING REAR WHEEL R/S		1.00
8	60010015000	Spacer ring 03		1.00
9	6031017000030	RIM REAR 5,0X17"		1.00
10	60310271000	SPOKE 5/4.37/M5		18.00

11	60310371000	SPOKE 5/4.37/M5		18.00
12	60310072100	SPOKE NIPPLE QUADRAX M5		36.00
14	60310277100	GASKET RUBBER 5"X17"		1.00
15*	60310173200	RIM BAND 17"		1.00
16	59009062016	SPECIAL SCREW M6X16 WS=8 10.9		6.00
17	60142021100	Phonic wheel ABS, rear		1.00
18	0980101253	Hexag. nut DIN 980V M10X1.25 S		6.00
20	60010051042	REAR SPROCKET 42-T 03		1.00
21	60010052000	SPROCKET SCREW M10X1,25 03		6.00
23	6011005004433	SPROCKET SUPPORT CPL. BLACK		1.00
24	60110012000	SPACER BUSH. SPROCKET SUPP. 06		1.00
25	60110016000	NILOS RING 6006AV		1.00
26	0625060060	BALL BEARING 6006 DDU2CG23S6NM		2.00
27	60110014000	SPACER BUSH. SPR. SUPP. IN. 06		1.00
28	54610459000	Rubber damping block 91		6.00
29	6031006000030	BRAKE DISK REAR		1.00
32	60310081044	AXLE REAR CPL.		1.00
33	60010084000	Chain tension adjuster, right,		1.00
34	61010086000	Collar nut M25X1.5 WS=32 05		1.00
35	58414030000	HH COLLAR NUT M10X1,25 WS=13	MINI ADV.	2.00
36	50304040100	screw M10x1.25x50 WS10		2.00
37	60010565118	CHAIN 525 INCL. MASTER LINK	RIVET TOOL NECESSARY	1.00
38	60010466000	MASTER LINK FOR CHAIN 525		0.00
39	60312033000	TIRE AIR PRESSURE SENSOR		1.00
40	60312033050	NUT AIR PRESSURE SENSOR		1.00
97	00050002013	DRIVETRAIN KIT ADV/-S 17T/42T		0.00
98	60310015000	REAR WHEEL REP. KIT ADV 13-14		0.00
99	60312034044	VALVE KIT AIR PRESSURE SENSOR		1.00

* = New part