



siehe Settingliste
see setting list

Pos	Part Number	Description	Additional Text	Quantity
1	46180807S2	Shock absorber upper part		1.00
2	46180654S18	Shock absorber lower part		1.00
3	50180213S18	DCC-COMPR. DAMP. CONTROL CPL.		1.00
4	50180095	HS cylinder-head screw R1/8 I8		1.00
5	52000087	Sticker WP warning 47x63		1.00
6	46180766	Lock nut shock M54x1,5		1.00
7	46180855	Adjustment nut shock M54x1,5		1.00
8	91110015S	SPRING 185MM 70N/MM (61)		0.00
8	91110016S	SPRING 185MM 75N/MM (61)		1.00
9	46180396	Spring retainer 28x73x15		1.00
10	46810010	Round-wire snap ring 49x1,5		1.00

11	46812011	Piston ring 44x46x8		1.00
12	R15002	REPAIR-KIT GASKET 05		1.00
13	R15006	REPAIR KIT BEARINGS 07		1.00
14	50180751S1	SHOCK ABSORBER FLUID 5 LT		1.00