



Pos	Part Number	Description	Additional Text	Quantity
1	90134005033	SHIFT SHAFT CPL.		1.00
2	90134009000	TENSION SPRING		3.00
3	90134022000	SPRING BUSHING		1.00
4	90134014000	RETURN SPRING		1.00
5	90134050000	STOP DISK 14X30X1,5		1.00
6	90134016000	SPRING GUIDE		1.00
7	90634031010	BAFFLE SHIFT LEVER		1.00
8	J025060223	HH COLLAR SCREW M6X22 SW10		1.00
9	90634040033	TENSION ROD CPL.		1.00
10	90134031133	SHIFTING LEVER CPL.		1.00
11	J625060800	BEARING CHANGE LEVER		2.00

12	90134035000	GEAR SHIFT LEVER RUBBER		1.00
14	90134031103	SPACER SHIFTING LEVER		1.00
15	90134034100	HH COLLAR SCREW M8X30 SW10		1.00
16	90134002000	SHIFT FORK COUNTER		2.00
17	90134019000	GEAR SHIFT RAIL		1.00
18	90134001000	SHIFT FORK MAIN		1.00
19	90134015003	AH SCREW M6X20 SELF LOCKING		1.00
20	90134015000	SHIFT DRUM LOCATING		1.00
21	90134013000	Parallel pin		1.00
22	90134012002	SPACER		1.00
23	90134012000	SHIFT ROLLER		1.00
24	90134012003	CONTACT SPRING		1.00
25	90134012001	BOLT FOR GEAR INDICATOR		1.00
26	90134025000	SCREW LOCKING LEVER		1.00
27	90134030000	WASHER LOCKING LEVER		1.00
28	90134024033	LOCKING LEVER CPL.		1.00
29	90134039000	WASHER 6X12,8X1,2		1.00
30	90134023000	ARRESTING LEVER SPRING		1.00
31	90134190000	GEAR SHIFT RAIL COUNTER		1.00
32	90134031020	thrust washer, gear shift leve		1.00