





Pos	Part Number	Description	Additional Text	Quantity
1	91236020033	CYLINDER HEAD CPL.		1.00
2	90236052000	VALVE COVER CPL.		1.00
3	90236053000	GASKET VALVE COVER		1.00
4	90236054000	GASKET SPARK PLUG SHAFT		1.00
5	90236074000	SPARK PLUG SHAFT		1.00
6	91230036000	GASKET CYLINDER HEAD		1.00
7	J025060356	HH-COLLAR SCREW M6X35 WS8		4.00
8	J025060401	HH COLLAR SCREW M6X40		2.00
9	90236018000	CHAIN GUIDE TOP		1.00
10	90130064000	OIL JET		4.00
11	90236025000	VALVE GUIDE		4.00
12	90130024000	PIN DOWEL 8X6,4X14MM		2.00
13	J912061023	SOCKET HEAD SCREW M6X102		2.00
14	J125070003	WASHER 7X11X2		2.00
15	J912101449	SOCKET HEAD SCREW M10X144		4.00
16	J125110003	WASHER 11,2X18X2		4.00
17	90136020001	STUD M8		2.00
18	90136038000	FLANGED NUT M8 H7,5 WS12		2.00
19	90138091001	O-RING		1.00
20	90138091000	OIL PRESSURE SENSOR		1.00
21	90235019000	PIPE COOLANT		1.00
22	90135047000	TEMPERATURE SENSOR		1.00
23	90135047001	O-RING		1.00
24	90136052020	VALVE COVER SCREW		4.00
25	90136052010	DECOUPLING ELEMENT		4.00
26	90236024000	PLUG		1.00
27	J025060453	HH COLLAR SCREW M6X45		2.00
28	J770029819	O-RING 29,8X1,9		2.00