




Pos	Part Number	Description	Additional Text	Quantity
1	B330300100004	FRAME ORANGE		1.00
2	0025080406	HH COLLAR SCREW M8X40 TX40		2.00
3	B3303039000	FOOTREST PLATE R/S		1.00
4	B3303038000	FOOTREST PLAT L/S		1.00
5	B3303042000	Bushing		1.00
6	GP3032170000	PIN 2,5X11,8 G2		2.00
7	B3303041000	FOOTREST		2.00
8	0025080356	HH collar screw M8x35 TX40		2.00
9	M3203040201	FOOTPEG CAP		2.00
10	0025080206S	HH collar screw M8x20 TX40 SL		4.00
12	69008021080	clip nut M5		7.00
13	62142041000	DAMP. COMPONENT ABS MODUL		2.00
14	B3303070000	AIRBOX PIN		1.00

15	0934050003	HEXAGON NUT DIN0934-M 5		1.00
18	0912100453	AH SCREW DIN0912-M10X45		1.00
19	B3303013000	WASHER		4.00
20	B3303016000	FRONT ENGINE SPACER L/S		1.00
21	0912100803	SOCKET HEAD SCREW M10X80		1.00
23	M3303011000	CHAIN ROLLER		1.00
24	B3303083000	NUT FOR SWING ARM PIVOT		2.00
25	0912050103	AH SCREW DIN0912-M 5X10		2.00
26	B3303093000	PIVOT ADJUSTMENT +/- 3MM		0.00
26	B3303094000	PIVOT ADJUSTMENT +/- 4MM		0.00
26	B3303090000	PIVOT ADJUSTMENT +/- 0MM		2.00
26	B3303091000	PIVOT ADJUSTMENT +/- 1MM		0.00
26	B3303092000	PIVOT ADJUSTMENT +/- 2MM		0.00
27	M3203081100	SWING ARM AXLE		1.00
28	60003014000	ENGINE BRAC. SCREW M10X206 03		2.00
29	B3303010000	REAR ENGINE SPACER TOP		1.00
30	M3303010000	REAR ENGINE SPACER BOTTOM		1.00
31	B3303012000	ENGINE SPANNER R/S		2.00
32	54630044000	COLLAR NUT M10 WS=13		2.00
33	54603055052	PRESS NUT M5		4.00
34	50307012000	ADH. FOIL TRANSP. 80X80 MM 04		2.00
35	B3303400001	BRACKET FOR LAP TRIGGER		1.00
36	54603055052	PRESS NUT M5		2.00
37	0738050101	BUTT. HEAD SCREW ISO7380 M5X10		2.00
38	M3211000042	PRESS NUT M3		4.00