



#, ⑤
+ GETRIEBELAGER
TRANSMISSION BEARINGS
(2 x 0625 006087,
1 x 0625 060030, 0625 060031,
0625 060042, 0625 062058,
0625 618050)

| Pos | Part Number | Description | Additional Text | Quantity |
|-----|---------------|--------------------------------|-----------------|----------|
| 1* | 52330000444 | ENGINE CASE CPL. W. TR.BEAR. | | 1.00 |
| 3 | 5033000220098 | IGNIT.COVER 125/200 MAG. 01 | | 1.00 |
| 5 | 54630027000 | DOWEL BUSHING 13,8X11X12 | | 2.00 |
| 21 | 58030021000 | OILDRAIN PLUG W.MAG. M 12X1,5 | | 1.00 |
| 22 | 58038022000 | CU-seal ring DIN7603-12X18X1.5 | | 1.00 |
| 39 | 50330039000 | ENGINE CASE GASKET 0,5MM '98 | | 1.00 |
| 40 | 50330040100 | IGNITION COVER GASKET 2001 | | 1.00 |
| 42 | 0015060503 | HH COLLAR SCREW M 6X50 WS=8 | | 6.00 |
| 43 | 0015060553 | HH COLLAR SCREW M 6X55 WS=8 | | 5.00 |
| 44 | 0015050163 | HH COLLAR SCREW M 5X16 WS=8 | | 4.00 |
| 45 | 0015060603 | HH COLLAR SCREW M 6X60 WS=8 | | 1.00 |

| | | | | |
|----|-------------|-----------------------------|--|------|
| 92 | 50330092000 | OIL GUARD GROMMET 25X31 '98 | | 1.00 |
| 99 | 50330099000 | GASKET SET 125-200 '98-'05 | | 1.00 |

* = New part