



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|-------------|----------------------------|-----------------|----------|
| 1 | 93511075200 | WIRING HARNESS | | 1.00 |
| 2 | 90111060100 | HORN 82 DIA | | 1.00 |
| 3 | 90111060010 | WASHER PLAIN 8,4X25X2 | | 1.00 |
| 4 | J025080123 | HH COLLAR SCREW M8X12 SW12 | | 1.00 |
| 5 | 90611053000 | BATTERY 12V/8AH | | 1.00 |
| 6 | 90511054001 | BRACKET RUBBER FOR BATTERY | | 1.00 |
| 7 | 90611057000 | relay (interlock) | | 6.00 |
| 8 | 90611157000 | RELAY (AUX1DIODE) | | 1.00 |
| 9 | 93511097000 | EARTH CABLE | | 1.00 |
| 11 | 90511034000 | voltage regulator | | 1.00 |
| 12 | 90511134010 | BRACKET VOLTAGE REGULATOR | | 1.00 |
| 13 | J025060303 | FLANGED BOLT M6X30 WS10 | | 1.00 |
| 14 | J025060253 | bolt flanged M6X25 | | 1.00 |
| 15 | J025060109 | HH-COLLAR SCREW M6X10 SW8 | | 2.00 |

| | | | | |
|----|-------------|--------------------------------|--|------|
| 16 | 93541088000 | rollover sensor | | 1.00 |
| 17 | J025050103 | HH-COLLAR SCREW M5X10 | | 2.00 |
| 21 | 90511097000 | GROUND CABLE | | 1.00 |
| 22 | 90811059000 | STARTER CABLE | | 1.00 |
| 23 | 90111058000 | STARTER RELAY | | 1.00 |
| 26 | 75011088005 | FUSE MINI 5A | | 1.00 |
| 26 | 75011088010 | FUSE 10A 07 | | 3.00 |
| 26 | 75011088015 | FUSE 15A 07 | | 5.00 |
| 26 | 75011088030 | FUSE 30A | | 1.00 |
| 30 | 93539010000 | Start OK control unit | | 1.00 |
| 31 | 90511030000 | indicator relay | | 1.00 |
| 32 | 93811043000 | resistor | | 1.00 |
| 34 | 93811099000 | wiring harness temperatur sens | | 1.00 |
| 34 | 93511084000 | PIGTAIL PH-3 FUEL PUMP | | 1.00 |
| 34 | 90838091000 | Pigtail oil pressure switch | | 1.00 |
| 34 | 93042033000 | Cable earth ABS | | 1.00 |