




Pos	Part Number	Description	Additional Text	Quantity
1	M3233080144	BEARING SHIEL CPL.		1.00
2	0625062035	BALL BEARING 6203 JR2 C3		1.00
3	0625618050	BALL BEARING 61805 C3		1.00
4	0625062054	BALL BEARING 6205 C3 NTN		1.00
5	78033132000	TAB WASHER BEARING COUNT.SHAFT		1.00
6	75030085000	RETAINING PLATE F. CS BEARING		3.00
7	0019050106S	hex lobe countersunc screw M5x		5.00
8	0402061000	NEEDLE ROLLER ZRB 6X10		3.00
9	54632095000	needle sleeve HK 1412 14x20x12		2.00
10	M3234012233	SELECTOR DRUM CPL.		1.00
11	M3234013000	SHIFTING ADJUSTMENT ASSY		1.00
12	0912060353	AH SCREW DIN0912-M 6X35		1.00
13	77330067138	SCRW M7-1,0X38		5.00
14	M3234016200	BRACKET		1.00
15	M3234017200	THRUST BOLT		1.00
16	0625061806	BALL BEARING 61806		1.00

17	07700240251	o-ring 24.00x2.50 Viton		1.00
18	60211023100	GEAR-POSITION SENSOR		1.00
19	M3434012102	BRACKET		1.00
20	0025050126	HH collar screw M5x12 TX30		3.00
21	M3234001000	SELECTOR FORK 1G/3G		1.00
22	M3234002000	SELECTOR FORK 2G/4G		1.00
23	M3234021000	SHIFT RAIL 1G/4G/2G/3G		1.00
24	0402061480	NEEDLE ROLLER DIN5402 6X14,8		2.00
25	M3234003000V01	SELECTOR FORK 5G/6G		1.00
26	0402060120	CYLINDER ROLLER 6X12		1.00
27	M3234020000	SHIFT RAIL 5G/6G		1.00
28	0025060306	HH collar screw M6x30 TX30		1.00
29	50232050000	WASHER 6,2X18X2	125	1.00
30	M3234024000V01	STOP LEVER ASSY		1.00
31	M3234023000V02	STOP LEVER SPRING		1.00
32	M3234022000V01	BUSH STOP LEVER		1.00
33	M3234005033	SHIFT SHAFT CPL.		1.00
34	0934060003	Hex. nut DIN 934 M6		1.00
35	M3234007002	ADJUSTING SCREW M6		1.00
36	M3234005054V01	PRESSURE SPRING		1.00
37	M3234014000V10	OUTER SPRING GUIDE		1.00
38	M3234015000V01	LEG SPRING		1.00
39	M3234014000V12	INNER SPRING GUIDE		1.00
41	0760142461	SHAFT SEAL RING 14X24X6B VITON		1.00
42	0025060206	HH collar screw M6x20 TX30		1.00
43	B3334030000	SHIFT SHAFT LEVER M6		1.00
59	77038013100	BUSHING PIN		1.00
60	77238061050	AXIAL-CIRCLIP		1.00
61	0025050106	HH collar screw M5x10 TX30		1.00