



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|----------------|-------------------------------|-----------------|----------|
| 1 | 6030711314433A | FUEL TANK CPL. | | 1.00 |
| 2 | 58507003200 | Fuel cock cmpl. | | 2.00 |
| 3 | 0770020130 | O-RING 1,78x10,82x14,38 2-013 | | 2.00 |
| 4 | 0025060126 | HH collar screw M6x12 TX30 | | 4.00 |
| 5 | 60307018000 | EXPANSION HOSE FUEL TANK | | 1.00 |
| 6 | 60307017000 | FUEL HOSE TANK/CONNECTOR | | 1.00 |
| 7 | 00050157706 | Variable one-ear clamp 15.7mm | | 2.00 |
| 9 | 5850701030030 | Plug CPC black 05 | | 1.00 |
| 10 | 60307053000 | SEAT LOCK COVER | | 1.00 |
| 11 | 60307016000 | FUEL HOSE 1 CPL. | | 1.00 |
| 12 | 0024060206 | HH collar screw M6x20 TX30 | | 2.00 |
| 13 | 58507012000 | O-ring VITON f. plug CPC 0 | | 1.00 |

| | | | | |
|-----|----------------|--------------------------------|----------|------|
| 14 | 60307020000 | TANK RUBBER | | 2.00 |
| 15 | 60307009000 | TANK CAP RING | | 1.00 |
| 16 | 60307037000 | WIRE HOLDER FUEL HOSE | | 1.00 |
| 17 | 60307016010 | HEAT PROTECTION | | 1.00 |
| 20 | 60307025000 | SPECIAL SCREW M6X32.5 ISA 40 | | 2.00 |
| 21 | 69007028000 | COLLAR BUSH. 6,2X10X21X14MM 08 | | 2.00 |
| 22 | 60307080000 | GAS LEVEL SENSOR | | 1.00 |
| 23 | 0912050163 | AH collar screw DIN 912 M5x16 | | 2.00 |
| 24 | 60307008000 | TANK CAP | | 1.00 |
| 25 | 0912050253 | AH SCREW DIN0912-M 5X25 | | 6.00 |
| 26 | 61007065000 | collar bushing, front tank hol | | 2.00 |
| 27 | 61007060000 | collar bushing, bearing, outsi | | 1.00 |
| 28 | 0912080403 | AH collar screw DIN0912 M8x40 | | 1.00 |
| 29 | 60007126001 | HOSE 5,4X9,4 NBR, METER | | 1.00 |
| 30* | 60038039000 | DISTANCE HOLDER 10/10 BLACK | | 1.00 |
| 31* | 69015019010 | HOSE CONNECTION STRAIGHT | | 1.00 |
| 32 | 60307008150 | HOSE TANK BREAT. | | 1.00 |
| 33 | 60307050000 | SEAT LOCK CPL. | | 1.00 |
| 34 | 0738060201 | FLAT HEAD SCREW ISO7380 M6X20 | | 2.00 |
| 35 | 60307140100 | SEAT R | | 1.00 |
| 36 | 60307140050 | SEAT COVERING | | 1.00 |
| 37 | 60307080090 | Gasket fuel lever sensor | | 1.00 |
| 38 | 69013099050 | Screw for expansion tank | ONLY AUS | 2.00 |
| 39* | 6031200810030 | GRIP L/S BLACK | | 1.00 |
| 40* | 6031200920030 | HAND GRIP R/S | | 1.00 |
| 41 | 6031201000033S | BAGGAGE CARRIER BRIDGE | | 1.00 |
| 42 | 0035080406 | AH-COLLAR SCREW M8X40 ISA45 | | 4.00 |
| 43 | 59001092050 | SPECIAL SCREW M6X12,5 WS=8 | | 2.00 |
| 44 | 0021060003 | Washer DIN9021-A 6.4 | ONLY USA | 2.00 |
| 48 | 60307040080 | HEAT PROTECTOR | | 1.00 |
| 49 | 60307050020 | LOCK CYLINDER SEAT LOCK | | 1.00 |
| 50 | 60307008190 | GASKET TANK CAP | | 1.00 |
| 53 | 69007027000 | rubber grommet, tank mounting | | 2.00 |

* = New part