



Pos	Part Number	Description	Additional Text	Quantity
1	60630000044	ENGINE CASE CPL. W. BEARINGS		1.00
2	0019050106S	hex lobe countersunc screw M5x		7.00
3	61230084000	BRACKET FOR BEARING INSERT 08		2.00
5	0025080306	HH collar screw M8x30		3.00
6	6033006600033S	ENGINE BRACKET R/S BLACK		1.00
8	62638084044	OIL SIGHT GLASS CPL.		1.00
9	0025050166	HH collar screw M5x16 TX30		2.00
10	75038041200	oil filter cover		1.00
11	07700390261	O-RING 39,34X2,62		1.00
12	0025060256	HH collar screw M6x25 TX30		2.00

13	69030060144	PINION COVER CPL.		1.00
14	60330047144	CHAIN FAIL. PROTECTION CPL.		1.00
15	61330157050	SLIDE BEARING		1.00
16	60030010000	SWING BEARING OUTSIDE LC8 03		2.00
17	60030023000	DOWEL 20,1X24X12 03		1.00
18	49030090000	DOWEL 9,8 X 7 X 10	FS-E	3.00
19	61230044000	STUD M6X110 08		4.00
20	0025060806	HH COLLAR SCREW M6X80 TX30		12.00
21	61230043000	CASE SCREW M8X125 AS 08		5.00
22	0025060906	HH COLLAR SCREW M6X90 TX30		4.00
23	0025060606	HH collar screw M6x60 TX30		3.00
24	60038029200	REDUCING JET "30" M6X0,75		1.00
25	07700900151	O-RING 9x1,5 V80 SH		3.00
26	77336056095	SCREW PLUG		2.00
27	77236080100	threaded plug		1.00
28	0018050103	INT. TORX OVAL HEAD M 5X10 8.8		2.00
29	57031523100	MAIN JET 100 DELLORTO		1.00
30	60005026000	SAS Reed Valve		1.00
31	45038017000	SEAL RING 8X14X1 AI		1.00
32	0025080166	HH COLLAR SCREW M8X16 TX40		1.00
33	0025080206S	HH collar screw M8x20 TX40 SL		1.00
34	74003021000	BUSHING 8.2 X 12 X 6		1.00
35	0025060166S	HH collar screw M6x16 TX30 SL		1.00
99	61230099100	GASKET KIT ENGINE CPL.		1.00