



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|-------------|--------------------------------|-----------------|----------|
| 1 | 90230000144 | ENGINE CASE CPL. | | 1.00 |
| 2 | 90130022000 | VENTILATION CONNECTOR | | 1.00 |
| 4 | J011080203S | FLANGED BOLT M8X20 | | 1.00 |
| 5 | J472025120 | CIRCLIP 25X1,2 | | 1.00 |
| 6 | J760122455 | SHAFT SEALING RING 12X24X5,5 | | 1.00 |
| 7 | 90233010001 | DEEP GROOVE BALL BEARING | | 1.00 |
| 8 | 90234030000 | BUSH SHIFT RAIL | | 2.00 |
| 9 | J618131912 | NEEDLE ROLLER BEARING HK1312 | | 2.00 |
| 10 | J625063040 | DEEP GROOVE BALL BEARING 6304 | | 1.00 |
| 11 | 90230079000 | STOPPER BALANCER SHAFT BEARING | | 3.00 |

| | | | | |
|----|-------------|--------------------------------|--|-------|
| 12 | 90130078001 | FLANGED BOLT 6X12 | | 3.00 |
| 13 | 90130004004 | Bearing ball | | 1.00 |
| 14 | J625063320 | BALL BEARING 22X56X16-C3L- | | 1.00 |
| 15 | J625062122 | BALL BEARING 15X35X11-C3-1 | | 1.00 |
| 16 | 90238014000 | OIL PIPE | | 1.00 |
| 17 | 90230066100 | OIL NOZZLE | | 1.00 |
| 18 | 90230077000 | OIL SEAL OUTPUT SHAFT | | 1.00 |
| 19 | J472037150 | CIRCLIP 37X1,5 | | 1.00 |
| 20 | 90130003004 | Seal - oil | | 1.00 |
| 21 | 90130003007 | DOWEL D14 | | 2.00 |
| 22 | 90211023000 | GEAR-POS.SENSOR INC.PULS. COIL | | 1.00 |
| 23 | J011050133 | HH COLLAR SCREW M5X13 SW8 | | 5.00 |
| 24 | J025050166 | HH COLLAR SCREW M5X16 SW8 | | 2.00 |
| 25 | 90230060000 | BRACKET | | 1.00 |
| 26 | 90230042000 | BRACKET | | 1.00 |
| 27 | 90230047000 | CHAIN GUARD | | 1.00 |
| 28 | J005060123 | FLAT HEAD SCREW M6X12 PH | | 3.00 |
| 29 | J025060350 | FLANGED BOLT M6X35 WS8 | | 11.00 |
| 30 | J028060753S | FLANGED BOLT M6X75 | | 5.00 |
| 31 | 90230066000 | OIL NOZZLE | | 1.00 |
| 33 | 90230142000 | BRACKET GEAR-POSITION SENSOR | | 1.00 |