



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|-------------|-------------------------------|-----------------|----------|
| 1 | 90504030044 | SWING ARM CPL. | | 1.00 |
| 3 | 90104050000 | SPLASH PROTECTOR | | 1.00 |
| 4 | 90104060000 | CHAIN GUARD CPL. | | 1.00 |
| 5 | 90104037000 | Shaft swing arm L=299mm | | 1.00 |
| 6 | 90104038000 | FLANGED NUT M14X1.5 | | 1.00 |
| 7 | J025060083 | HH COLLAR SCREW M6X8 SW8 | | 2.00 |
| 8 | 90104067000 | BUCKET | | 2.00 |
| 9 | 90104040000 | BOLT HEX M10X1.25X50 WS10 | | 2.00 |
| 10 | 90104010002 | flanged hex nut M10x1.25 WS13 | | 2.00 |
| 11 | 90104042000 | hex thrust washer | | 2.00 |
| 12 | 90104046000 | swingarm adjusting ring | | 2.00 |
| 13 | 90104034001 | OIL SEAL RING 25X32X7 | | 4.00 |
| 14 | 90104036000 | Thrust washer 22.2x31.7x1 | | 2.00 |
| 15 | 90104034000 | cup for radial shaft seal | | 4.00 |

| | | | | |
|----|-------------|-----------------------------|--|------|
| 16 | 90104031000 | Igus plain bearing | | 4.00 |
| 17 | 90104032000 | sleeve bushing 15.1x20x38 | | 2.00 |
| 18 | 90113047000 | brake hose guide | | 2.00 |
| 19 | J011050133 | HH COLLAR SCREW M5X13 SW8 | | 2.00 |
| 20 | 0017060303 | SPECIAL SCREW T60 6X30 WS=6 | | 1.00 |
| 21 | J025050503 | HH COLLAR SCREW M5X50 SW8 | | 1.00 |
| 22 | 90204060001 | HH COLLAR NUT | | 1.00 |
| 25 | J025060169 | HH COLLAR SCREW M6X16 SW8 | | 2.00 |
| 26 | 90604062000 | chain slider bushing | | 2.00 |
| 28 | 90104040100 | screw M5x0.8x30 | | 1.00 |
| 29 | 90504067000 | WASHER CHAIN SLIDING GUARD | | 1.00 |
| 30 | 90104070020 | SLEEVE CHAIN GUARD | | 0.00 |
| 31 | 90904070020 | SLEEVE CHAIN GUARD | | 0.00 |
| 96 | 90104060110 | CHAIN PROTECTION KIT DUKE | | 0.00 |
| 97 | 90106010010 | SPLASH GUARD KIT 390 DUKE | | 0.00 |
| 98 | 90104230010 | SWINGARM REP. KIT 11-17 | | 0.00 |
| 99 | 90104066310 | CHAIN GUARD KIT 125/200 | | 0.00 |