



Pos	Part Number	Description	Additional Text	Quantity
1	70009001144	FRONT WHEEL CPL. 14		1.00
2	70009010044	FRONT WHEEL HUB CPL. 12		1.00
3	70009011000	BEAR.SPACER TUBE FRONT D22MM		1.00
4	0760324271	SHAFT SEAL RING 32X42X7 BSL		2.00
5	0625069050	BALL BEARING 6905 J1LLUC3		2.00
6	70009012000	SPACER BUSHING D=22MM		2.00
7	7000907123230	SPOKE FRONT 232MM BLACK		32.00
8	77109072000	Spoke nipple M4.5 AL		32.00
9	70009070100	FRONT RIM 21X1,6-32		1.00
10	50309073000	Tube protector 21"		1.00
11	78109090000	RIM LOCK 1,60"		1.00
12	77110090050	NUT FOR WHEEL HOLDER		1.00
13	70009081050	PLUG BUSHING SW17 '12		1.00
14	70009081000	AXLE FRONT D=22 '12		1.00
15	70009082000	AXLESCREW M20X1.5 SW17		1.00
16*	72509060000	BRAKE DISC FRONT D=260MM		1.00
17	59009062013	SPECIAL SCREW M6X13 WS=8 10.9		4.00
98	70009015000	FRONT WHEEL REP. KIT		0.00
99	00050000961	SPOKE KIT FRONT '21'		0.00

* = New part