




| Pos | Part Number | Description                    | Additional Text | Quantity |
|-----|-------------|--------------------------------|-----------------|----------|
| 1   | 0985060003  | Self lock. nut DIN985-M6-A2    |                 | 1.00     |
| 2   | 0125060003  | WASHER DIN0125-A 6,4           |                 | 1.00     |
| 3   | 60440001000 | STARTER MOTOR                  |                 | 1.00     |
| 4   | 0618101410  | needle sleeve HK 1010 10x14x10 |                 | 1.00     |
| 5   | 60038007010 | washer 10x16x0.5               |                 | 1.00     |
| 9   | 0625060016  | deep groove ball bearing 6001. |                 | 1.00     |
| 10  | 60340117100 | torque limiter 10/55 cpl.      | L-PART          | 1.00     |
| 14  | 61230058050 | BEARING BOLT 15X39 08          |                 | 1.00     |
| 15  | 0405151913  | needle roller and cage assy. K |                 | 1.00     |
| 16* | 60340022000 | IDLER GEAR 43T                 |                 | 1.00     |
| 17  | 61230057060 | STOP DISK 15,2X25X1            |                 | 2.00     |
| 18  | 0618354220  | NEEDLE BUSH HK3520 35/42/20    |                 | 1.00     |
| 21  | 60439005000 | ROTOR CPL.                     |                 | 1.00     |

|    |             |                            |  |      |
|----|-------------|----------------------------|--|------|
| 22 | 0912060206  | AH SCREW DIN 912 M6X20     |  | 8.00 |
| 23 | 60340020000 | FREEWHEEL GEAR CPL.        |  | 1.00 |
| 24 | 0025060256  | HH collar screw M6x25 TX30 |  | 2.00 |
| 25 | 60040027000 | FREEWHEEL HOLDER 03        |  | 1.00 |
| 26 | 60040027050 | SUPPORTING SLEEVE 03       |  | 2.00 |
| 27 | 0025060300  | HH COLLAR SCREW M6X30 INOX |  | 2.00 |
| 28 | 0770033020  | O-RING 33,75X2,00          |  | 1.00 |

\* = New part