



Pos	Part Number	Description	Additional Text	Quantity
1	60029057000	PLIERS F. VAR.ONE-EAR CLAMP 03		1.00
2	60029057100	PLIERS F. CLAMP 03		1.00
4	60029018000	INTERN.BEAR.PULLER 28 MM		1.00
5	60029055100	ATTACHMENT WHEELED JACK 03		1.00
6	58303070000	STOP RUBBER M8		2.00

9	60029020000	RIVET TOOL 03		1.00
10	6899785	LOCTITE 243 BLUE 5 ML		1.00
11	60029056000	ANVIL DOLLY 03		1.00
12	60010013000	SPACER BUSH. REAR WHEEL R/S 03	FOR SWINGARM BEARING	1.00
13	58429086000	PRESS. TOOL F. LINK BEAR. LC4		1.00
14	58429091000	MOUNT.TOOL STEER.HEAD BEAR.LC4		1.00
15	58429092000	DISMOUNT. TOOL F. BEARINGS LC4		1.00
16	58429089000	HOLDING TOOL CHASSIS LC4		1.00
17	61029055000	STAND FOR ENGINE DEMOUNTING		1.00