



Pos	Part Number	Description	Additional Text	Quantity
1*	58611075000	WIRING HARNESS 640 SM 05		1.00
2*	58611083000	SUPPORT BRACKET L/S 05		1.00
3	49007439000	CLAMP RSGU 15/12		2.00
4	0912050083	SHCS DIN 912 M5x8		1.00
5	58411057000	STARTER RELAY '96		1.00
6	58411096100	DIODE S3H-15 97		2.00
7	58011109110	Plug-in fuse, big 10A		0.00
8*	0981480133	SHEET MET.SCR.DIN7981- 4,8X13		2.00
9	0016050121	SCREW FOR PLASTIC 50X12	BLACK	8.00
10	58011109120	Plug-in fuse, big 20A		0.00
11*	45001070000	BRAKE CABLE CLAMP RSGU 9/12		1.00

12*	0797050003	TOOTH LOCK WASH. DIN6797-J 5,3		1.00
14	50311060100	DC HORN L.E.B. 03		1.00
15	0014060153	HH COLLAR SCREW M 6X15 WS=8		1.00
16	54603048100	clip nut M6		3.00
17	58411034100	VOLT.REGULATOR-RECTIFIER 12V		1.00
18	56509064100	Self locking nut M6 - 10		2.00
19*	58611183000	SUPPORT BRACKET R/S 05		1.00
21*	58611055000	BRACKET REGULATOR 05		1.00
24	58411050000	BRAKE LIGHT SWITCH FRONT SM 03	LC4 SUPERMOTO	1.00
25	58411049100	CLUTCH SWITCH 03		1.00
26	50311051100	BRAKE LIGHT SWITCH REAR '98	EXC EU+AUS	1.00
27	44611207200	FLASHER UNIT 97		1.00
28	44011076100	CABLE TIE 100/2,5MM BLACK		0.00
28	44011076200	CABLE TIE 200/3,6MM BLACK		0.00
28	44011076305	CABLE TIE 300/4,8MM BLACK		0.00
29*	58611076000	WIRING HARNESS REAR 05		1.00
30*	58611059000	STARTERCABLE L=810MM 05		1.00
31*	58611059050	BATTERY CABLE L=140MM 05		1.00
35	58411053100	BATTERY 12V 8,6AH 03		1.00
37*	58611097000	GROUND CABLE L=80MM 05		1.00
38*	0015060103	HH COLLAR SCREW M 6X10 WS=8	FC	1.00
39	58411098100	CONTACT WASHER M6 VSV-K6		2.00
40*	0015060123	HH COLLAR SCREW M 6X12 WS=8		1.00
41	58411045000	SIDE STAND SWITCH CPL. '97		1.00
54*	50303018000	RUBBER L=145MM		2.00
56*	58611058050	BRACKET STARTER RELAY 05		1.00
58*	58211058000	Starter reley 12V 99		1.00
73*	0985060003	Self lock. nut DIN985-M6-A2		1.00
84*	58611087050	BRACKET FUSE BOX 05		1.00
85*	58611059060	TERMINAL POST COVER 05		1.00
88*	0902060083	Oval head screw ISO 7380 M 6X8		2.00

\* = New part