



Pos	Part Number	Description	Additional Text	Quantity
1	61010001044	REAR WHEEL CPL. 05		1.00
3	61010011000	BEARING SPACER TUBE REAR 05		1.00
6	60010013000	SPACER BUSH. REAR WHEEL R/S 03	FOR SWINGARM BEARING	1.00
11	61010050044	SPROCKET SUPPORT CPL. 05		1.00
12	60010014000	SPACER BUSH. SPR. SUPP. IN. 03		1.00
14	60010016000	NILOS RING 7206 AVH 03		1.00
15	60010012000	SPACER BUSH. SPROCKET SUPP. 03		1.00
16	61010059000	DAMPING RUBBER 05		5.00
17	61010051138	REAR SPROCKET 38-T STEEL 05		0.00

17	61010051139	REAR SPROCKET 39-T STEEL 05		0.00
17	61010051140	REAR SPROCKET 40-T STEEL 05		0.00
18	61010056000	BOLT FOR SPROCKET SUPPORT 05		5.00
19	61010057000	NUT REAR SPROCKET 05		5.00
20	61010060000	BRAKE DISK REAR D=240MM 05		1.00
21	61009062018	SPECIAL SCREW M8X18 05		5.00
22	60010081044	WHEEL SPINDLE REAR CPL. 03		1.00
23	60010084000	Chain tension adjuster, right,		1.00
24	61010086000	Collar nut M25X1.5 WS=32 05		1.00
25	50304040000	SPEC. SCREW M10X1,25X40 WS=10		2.00
26	58414030000	HH COLLAR NUT M10X1,25 WS=13	MINI ADV.	2.00
27	60010165118	CHAIN 525 WITH MASTER LINK 03	NEED RIVET TOOL	1.00
28	60010066000	MASTER LINK FOR CHAIN 525 03	NEED RIVET TOOL	0.00
30	61010074000	BLINKER KIT		1.00
31	58709076000	VALVE CPL. BREMBO DUKE 2003		1.00