



Pos	Part Number	Description	Additional Text	Quantity
1	6000302330030	SIDE STAND "D" L=302MM		1.00
3	58203027200	SCREW FOR SIDE STAND M10X26,7		1.00
4	60003028001	SCREW SIDE STAND SPRING 03		1.00
5	60003028003	SUPPORT SIDE STAND SPRING 03		2.00
6	60003024000	SPRING FOR SIDE STAND 03		2.00
7	60003026000	SIDE STAND BRACKET 03		1.00
8	0015100303	HH COLLAR SCREW M10X30 WS=13		2.00
9	60003023001	SIDE STAND PICKUP CPL. 03		1.00
10	0015100243	HH COLLAR SCREW M10X24 WS=13		2.00
11	60011045000	SIDE STAND SWITCH 03		1.00
22	6000302240030	CENTER STAND L=333MM 05		1.00
23	60003030000	SPRING FOR CENTER STAND 03		2.00
24	60003022115	SPRING TENSIONER 03		1.00

25	0125080003	washer DIN 125 A -8.4		1.00
26	0015080303	HH COLLAR SCREW M 8X30 WS=10		1.00
27	56503093000	SPECIAL SCREW M10X55 WS=17		2.00
28	0125100003	washer DIN 125 A 10.5	ONLY FOR 640 DUKE	2.00
29	60003022020	BEARING BUSH CENTER STAND 03		2.00
30	60003022021	SPACER 10X16X38 MM 03		2.00