





ACHTUNG !!!
Mit dem Wellendichtring auch
die Wasserpumpenwelle wechseln.

CAUTION !!!
With the shaft seal ring also
change the water-pump shaft.



Pos	Part Number	Description	Additional Text	Quantity
1	0015060103	HH COLLAR SCREW M 6X10 WS=8	FC	2.00
2	0603061001	CU-SEAL RING DIN7603-6X10X1		2.00
3	0015060163	HH COLLAR SCREW M 6X16 WS=8	FE, FS	2.00
4	60035052000	WATER-PUMP COVER 03		1.00
5	60035053000	WATER-PUMP GASKET 03		1.00
6	59030023000	dowel sleeve 6x8x11.5		2.00
7	0014060153	HH COLLAR SCREW M 6X15 WS=8		1.00
8	60035055100	WATER-PUMP WHEEL LC8 03		1.00
9	60035055150	double-d washer 16x1 SST		1.00
10	0760123072	SHAFT SEAL RING 12X30X7 VITON	DOUBLE-LIP	1.00
11	0471120010	retaining ring DIN 471 12x1		2.00
12	0625069010	GROOVED BALL BEARING 6901V C3		2.00
13	0472240120	CIRCLIP DIN472 D=24X1,2		1.00
14	60035054000	WATER-PUMP SHAFT 03		1.00

15	0770250030	O-RING 25,00X3,00 NBR 70		2.00
16	60035021000	ALUMINUM TUBE WATER-PUMP+CLAMP		1.00
17	60035021050	FIXING CLAMP WATER-P. TUBE 03		1.00
18	0015060603	HH COLLAR SCREW M 6X60 WS=8		4.00