



Pos	Part Number	Description	Additional Text	Quantity
1	6100300100030	FRAME 990 DUKE 05		1.00
2	61003088000	PLUG SFL28 05		2.00
3	61003005000	ENGINE SUPPORT LEFT 05		1.00
4	61003006000	ENGINE SUPPORT RIGHT 05		1.00
5	0015100243	HH COLLAR SCREW M10X24 WS=13		4.00
6	54310086100	SELF LOCKING NUT M10 CU WS=14		4.00
7	60003013000	ENGINE BRAC. SCREW M10X172 03		1.00
8	60003014000	ENGINE BRAC. SCREW M10X206 03		1.00
9	60004076100	CHAIN SLIDING BLOCK 05		1.00
10	0017060204	EJOT PT SCREW K60X20 ALU WS=6	SX	2.00
11	61003038000	FOOTREST BRACKET FRONT L/S 05		1.00
12	61003039000	FOOTREST BRACKET FRONT R/S 05		1.00

13	54630044000	COLLAR NUT M10 WS=13		2.00
14	61034032000	COVER PLATE L/S 05		1.00
15	61013032000	COVER PLATE R/S 05		1.00
16	0738060101	Oval head screw ISK ISO7380 M6		4.00
17	61003050000	FOOTREST FRONT L/S CPL. 05		1.00
18	61003051000	FOOTREST FRONT R/S CPL. 05		1.00
19	60003044000	BOLT FOR FOOTREST REAR 03		4.00
20	61003042000	SPRING FOOTREST FRONT 05		2.00
21	0799060003	retaining washer DIN 6799 - 6		4.00
22	60003152000	ENGAGE PANEL FOOTREST L/S 03		2.00
23	60003052000	ENGAGE PANEL FOOTREST R/S 03		2.00
24	60003098000	RUBBER SLEEVE 03		2.00
30	61003002000	SUB FRAME ALUMINIUM 05		1.00
31	0015080303	HH COLLAR SCREW M 8X30 WS=10		4.00
32	61003002058	STEPPED WASHER 8,5X20X3,5 05		4.00
33	0926080003	STOP NUT DIN6926 M8 SS		4.00
34	61003048000	FOOTREST BRACKET REAR L/S 05		1.00
35	61003049000	FOOTREST BRACKET REAR R/S 05		1.00
36	54610052000	SPROCKET SCREW-AH M8X20 WS=6		4.00
37	60006001021	Distance rupper airbox 03		2.00
38	60003050000	FOOTREST CPL. L/S REAR 03		1.00
39	60003051000	FOOTREST CPL. R/S REAR 03		1.00
40	61003089000	PLUG SFL 22X1,8-3,5		2.00
50	61003052000	SPECIAL SCREW M8X18 06		6.00