



Pos	Part Number	Description	Additional Text	Quantity
1	62505007100	EXHAUST PIPE FRONT 05		1.00
2	62505008000	EXHAUST PIPE REAR 05		1.00
3	60005005000	GASKET 03		2.00
4	61005009000	SPACER BUSH. 8,5X15X7,5 05		2.00
5*	51010086100	self-locking nut M8 Cu		5.00
6	09081000000	PLUG DIN0908-M10X1 A2		2.00
7	0603100141	sealing ring DIN 7603 10x14x1	ONLY FOR LC4 ADVENTURE	2.00

10*	61005007049	CLAMP EXHAUST PIPE 05		1.00
11*	0015080353	HH COLLAR SCREW M 8X35 WS=10	FC	2.00
12	0125080003	washer DIN 125 A -8.4		1.00
13*	51005067000	INSOLATE WASHER 8,5X28X3		1.00
14*	58405050065	collar bushing 8.5x12x23.5x10		2.00
15*	62505015050	EXHAUST PIPE BRACKET FRT 06		1.00
16*	0015080403	HH COLLAR SCREW M 8X40 WS=10		1.00
20	61005051100	CLAMP CPL. D=53,2MM 05		1.00
21	58405005001	Graphite ring 45X50X25		1.00
29	0991080353	FLAT HEAD SCREW DIN7991-M 8X35		2.00
30	61005052000	EXHAUST CLAMP CPL. 05		1.00
31	62505048100	DISTRIBUTOR TUBE 05		1.00
32	0015080303	HH COLLAR SCREW M 8X30 WS=10		4.00
33	58303061100	SPECIAL WASHER ALU 8X24 MM ELO		2.00
34	62505069000	SPACER BUSH. 8,5X12X18MM 05		2.00
35*	54305068100	damp. component silicone grey		5.00
36	0015080163	HH COLLAR SCREW M 8X16 WS=10		6.00
37	62505047000	THERMAL SHIELD 05		1.00
38	58605083010	SCREW TORX M5X10 05		3.00
39	60005005002	EXHAUST GASKET 03		2.00
40	62505083100	SILENCER L/S 05		1.00
41	62505083000	SILENCER R/S 05		1.00
42	54308042000	RUBBER BUFFER		2.00
43	60005095000	CLAMP FOR SILENCER CPL. 03		2.00
44	60005085000	SILENCER/HANDLE HOLDER L/S 03		1.00
45	60005086000	SILENCER/HANDLE HOLDER R/S 03		1.00
46	0015080253	HH COLLAR SCREW M 8X25 WS=10		2.00
47*	0021080003	WASHER DIN9021-A 8,4		3.00
48	0797050000	TOOTH LOCK WASHER DIN6797-J		3.00

\* = New part