




Pos	Part Number	Description	Additional Text	Quantity
1	54609001544	FRONT WHEEL 1,6X21"EXCEL SX'9		1.00
2	56509010944	FRONT WHEEL HUB SILVER SX'94		1.00
3	56509011400	BUSHING SPACER TUBE 17,5X22X82		1.00
4	0625060037	GR.BALL BEAR. 6003-2RSH/C3HMTF		2.00
6	0760253571	SHAFT SEAL RING 25X35X7 BSL		2.00
7	54609051000	SPACER RING 17X25X7,5		1.00
8	54609051100	SPACER BUSHING 17X25X15		1.00
10	58309071234	SPOKE M5X234-15G 21" DDE		36.00
11	56509072000	STEEL NIPPLE M5		36.00
12	54609070100	FRONT RIM 1,6X21" EXCEL AL4	SX RACING	1.00
13	51009073000	RIM BAND 21"		1.00
14	51009075000			1.00
15*	54609074700	* TYRE 80/100-21" 51R MT18		1.00
16	51009100100	RIM LOCK VM1 (1,60")	ONLY FOR 19" WHEEL	1.00
17	50310090050	NUT FOR WHEEL HOLDER '96		1.00
20	56509060700	FRONT BRAKE DISK D=260MM		1.00
21	0015060163	HH COLLAR SCREW M 6X16 WS=8	FE, FS	6.00
22	56509064000	SELF LOCKING NUT M6		6.00
25	55009086000	PLUG SFL13		1.00
30*	50309081000	FRONT AXLE L=235MM		1.00
32	49032011000	HH COLLAR SCREW M10X20 WS=17		1.00

* = New part