




Pos	Part Number	Description	Additional Text	Quantity
1	58430000044	ENGINE CASE CPL.W.TRAN.BEAR'96		1.00
1*	5843000004429	ENGINE CASE CPL.W.TRAN.BEAR'97		1.00
5	50130027000	DOWEL 19 X15,1X12		1.00
6	51030026100	DOWEL 17 X 13 X 12		1.00
7	50130010000	CRANK CASE BUSH		2.00
9	58033097000	NEEDLE BEARING HK 2216		1.00
10	58330011000	SHIFT MECHANISM SUPPORT LC4'94		1.00
11	49030090000	DOWEL 9,8 X 7 X 10	FS-E	4.00
12	0015060353	HH COLLAR SCREW M 6X35 WS=8	LC4 ADVENTURE	1.00
13	0015060403	HH COLLAR SCREW M 6X40 WS=8	450 SMR	1.00
15	56530017000	RETAINING PLATE		1.00
16	0991060163	FLAT HEAD SCR. DIN7991-M 6X16		2.00
17	50332095000	NEEDLE BEARING HK 1212		2.00
18	58030080000	LOCATING SCREW M8 L=23	450/525 MXC, EXC	1.00

19	58030081000	CU-SEAL RING 8 X 14 X 3		1.00
20	58430039000	ENGINE CASE GASKET LC4-E '96		1.00
21	0985050103	OVAL HEAD SCR. DIN7985-M 5X10		1.00
23	0625160030	GROOVED BALL BEARING 16003 C3		1.00
24	0625618050	BALL BEARING 61805 C3		1.00
28	58440091000	STOP DISK 33 X 58 X 1,5		1.00
29	58011081000	CONTACT SCREW M10 '		1.00
30*	5833010100029			1.00
31	58330025000	CLUTCH COVER GASKET '94		1.00
33	58330020144	OIL DIPSTICK CPL. L=93MM '96		1.00
34	0770160030	O-RING 16,00X3,00 NBR 70		1.00
35	0015060253	HH COLLAR SCREW M 6X25 WS=8		8.00
36	0015060303	HH COLLAR SCREW M 6X30 SW=8	LC4, LC4 SM, DUKE	3.00
38	58333041000	BUMP RUBBER		1.00
40	58430060000	* SPROCKET COVER BLACK '96		1.00
41	54613038150	BUSHING 6,5X8X11		2.00
42	58430047000	CHAIN DAMPERSHEET 17T LC4-E		1.00
42	58430047100	CHAIN DAMPERSHEET 15/16T LC4-E		1.00
43	0015060253	HH COLLAR SCREW M 6X25 WS=8		2.00
44	58030021000	OILDRAIN PLUG W.MAG. M 12X1,5		1.00
45	58038017100	CU-SEAL RING DIN7603-22X27X2		1.00
46	58038019100	OIL DRAIN PLUG M22X1,5		1.00
47	58038022000	CU-seal ring DIN7603-12X18X1.5		2.00
48	0908120153	threaded plug DIN 908 M12x1.5	DUKE	1.00
50	58038023300	PRESSURE SPRING L=25MM D=1MM		1.00
51	58038028000	VALVE PISTON D=10MM		1.00
55	58430099000	GASKET SET LC4-E '		1.00

* = New part