

13	60030023000	DOWEL 20,1X24X12 03		1.00
14	0019050103	INT TORX FLAT HEAD M 5X10 8.8		2.00
15	0015060303	HH COLLAR SCREW M 6X30 SW=8	LC4, LC4 SM, DUKE	1.00
16	59030054000	JET 60 DELLORTO M6X0,75	MINI ADV.	2.00
17	60030063070	oil jet 70 M5		2.00
18	60030064000	OIL INJECT.TUBE CURVED "70"		2.00
19	60030039100	ENGINE CASE GASKET 0,5MM 05		1.00
20	60030060044	CHAIN SPROCKET COVER CPL. 03		1.00
21	60030047000	CHAIN FAIL. PROTECTION LC8 03		1.00
22	60032063000	ADAPTER F. HYDR. CLUTCH 03		1.00
25	0015060353	HH COLLAR SCREW M 6X35 WS=8	LC4 ADVENTURE	2.00
26	0985060003	Self lock. nut DIN985-M6-A2		2.00
27	49030029000	OIL DRAIN PLUG M10X1,5 AH-WS=6	ONLY FOR ADVENTURE USA	1.00
28	0603100141	sealing ring DIN 7603 10x14x1	ONLY FOR LC4 ADVENTURE	1.00
29	60038029000	REDUCING JET "30" M6X0,75		1.00
30	0015060403	HH COLLAR SCREW M 6X40 WS=8	450 SMR	4.00
31	0015060603	HH COLLAR SCREW M 6X60 WS=8		5.00
32	0015060653	HH COLLAR SCREW M 6X65 WS=8		3.00
33	0015060703	HH COLLAR SCREW M 6X70 WS=8		1.00
34	0015060753	HH COLLAR SCREW M 6X75 WS=8		4.00
37	0015060903	HH COLLAR SCREW M 6X90 WS=8		4.00
39	0916050042	THREAD PIN DIN916 M5X4-45H		2.00
40	0551060050	THREAD PIN DIN0551-M 6X 5		2.00
41	0125060003	WASHER DIN0125-A 6,4		1.00
42	60011094000	CABLE SUPPORT 03		1.00
43	0014060153	HH COLLAR SCREW M 6X15 WS=8		1.00
45	0912040103	AH.SCREW DIN0912-M 4X10		2.00
46	0770035020	O-RING 3,5X2,00 NBR		2.00
50	49030090000	DOWEL 9,8 X 7 X 10	FS-E	2.00
54	60030084000	BRACKET FOR BEARING INSERT 05		2.00
55	0015050123	HH COLLAR SCREW M 5X12 WS=8		6.00
99	60030099000	GASKET SET CPL. 03		1.00