



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|----------------|-------------------------------|-----------------|----------|
| 1* | 6100701310070A | FUEL TANK ORANGE 06 | | 1.00 |
| 2 | 61007041000 | BRACKET SEAT L/S 05 | | 1.00 |
| 3 | 61007042000 | BRACKET SEAT R/S 05 | | 1.00 |
| 4 | 0991050102 | Flat head screw DIN7991 M5X10 | | 4.00 |
| 5 | 61007034000 | MOUNTING BRACKET CPL. 05 | | 1.00 |
| 6 | 61007035000 | GAS-PRESSURE DAMPER 300N 05 | | 1.00 |
| 7 | 0799040003 | TAB WASHER DIN 6799-RS 4,0 A2 | | 2.00 |
| 8 | 0015060123 | HH COLLAR SCREW M 6X12 WS=8 | | 6.00 |
| 9 | 61007014000 | SPACER FUEL TANK 05 | | 2.00 |

| | | | | |
|-----|----------------|--------------------------------|--------------|------|
| 10 | 61007025000 | BRACKET FUEL TANK 05 | | 2.00 |
| 11 | 61007027000 | RUBBER BEARING FUEL TANK 05 | | 2.00 |
| 12 | 61007026000 | SPECIAL SCREW M10X36 AH 05 | | 2.00 |
| 13 | 61007065000 | collar bushing, front tank hol | | 2.00 |
| 14 | 61007060000 | collar bushing, bearing, outsi | | 1.00 |
| 15 | 0912080403 | AH collar screw DIN0912 M8x40 | | 1.00 |
| 16 | 60007008051 | SEAL. FLANGE F.TANK INSERT 03 | | 1.00 |
| 17 | 60007008150 | TANK INSERT 05 | | 1.00 |
| 18 | 60007008052 | SEAL. RING F. TANK INSERT 03 | | 1.00 |
| 19 | 61007008000 | TANK PLUG CPL. 05 | | 1.00 |
| 20 | 0912050083 | SHCS DIN 912 M5x8 | | 3.00 |
| 21 | 0912050123 | AH SCREW DIN0912-M 5X12 | | 1.00 |
| 22 | 0912050303 | AH SCREW DIN0912-M 5X30 | | 3.00 |
| 23 | 40011166100 | KEY BLANK LC4/DUKE/LC8 | | 0.00 |
| 25 | 60007024000 | CONNECT.PIECE F.OVERFLOW M7 03 | | 2.00 |
| 26 | 60007024050 | GASKET FOR CONNECTING PIECE 03 | | 2.00 |
| 27 | 60007026001 | HOSE NBR 5,4X9,4 PER METER | ONLY FOR USA | 0.00 |
| 30* | 61007080000 | GAS-LEVEL SENSOR 06 | | 1.00 |
| 31* | 0912050163 | AH collar screw DIN 912 M5x16 | | 2.00 |
| 32* | 61011094000 | CABLE TIE WITH PLUG M6 | | 2.00 |
| 40 | 6100805000070A | SPOILER L/S ORANGE 05 | WITH DECAL | 1.00 |
| 41 | 6100805100070A | SPOILER R/S ORANGE 05 | WITH DECAL | 1.00 |
| 42 | 60008045000 | SPECIAL WASHER D=16,5MM 03 | | 6.00 |
| 43 | 0012060123 | AH SCREW DIN6912 M6X12 | | 4.00 |
| 44 | 0014060133 | HH COLLAR SCREW M 6X13 WS=8 | | 4.00 |
| 45 | 54603048100 | clip nut M6 | | 2.00 |
| 46 | 61008050050 | AIR INTAKE L/S 05 | | 1.00 |
| 47 | 61008051050 | AIR INTAKE L/S 05 | | 1.00 |
| 50 | 0016050121 | SCREW FOR PLASTIC 50X12 | BLACK | 5.00 |
| 51 | 50235033300 | SNAP-NUT HOLDER M6 KP142 | | 2.00 |
| 52 | 6100802004470A | FRONT SPOILER CPL. ORANGE 05 | WITH DECAL | 1.00 |
| 53 | 61008020050 | THERMAL PROTECTION FOIL 05 | | 1.00 |
| 54 | 0012060164 | AH SCREW DIN6912 M6X16 SL | | 2.00 |
| 56 | 0017060203 | EJOT PT SCREW K60X20 WS=6 | MXC, EXC | 2.00 |
| 60 | 6100704000004 | SEAT ORANGE 05 | | 1.00 |
| 61 | 61007040010 | DISTANCE RUBBER SEAT 05 | | 6.00 |
| 62 | 61007050000 | SEAT LOCK 05 | | 1.00 |
| 63 | 61007052000 | SPACER RING SEAT LOCK 05 | | 1.00 |
| 64 | 61007050020 | SCREW M4 AF32 05 | | 1.00 |
| 65 | 61007050010 | WASHER AF150 05 | | 1.00 |
| 66 | 61007050040 | CLOSING PANEL TR248 05 | | 1.00 |
| 67 | 61007050050 | WASHER TR12.01 05 | | 1.00 |
| 68 | 61007050030 | NUT M19 X1 AF36 05 | | 1.00 |

* = New part