



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|---------------|--------------------------------|----------------------|----------|
| 1 | 6101000104457 | REAR WHEEL CPL. GREY 07 | | 1.00 |
| 2 | 0625062052 | Grooved ball bear. 6205-2RSHC3 | | 2.00 |
| 3 | 61010011000 | BEARING SPACER TUBE REAR 05 | | 1.00 |
| 4 | 0472052200 | CIRCLIP DIN0472-52X2 | | 1.00 |
| 5 | 0760305271 | Radial shaft seal 30X52X7 | | 1.00 |
| 6 | 60010013000 | SPACER BUSH. REAR WHEEL R/S 03 | FOR SWINGARM BEARING | 1.00 |
| 11* | 61010050144 | SPROCKET SUPPORT CPL. 06 | | 1.00 |
| 12* | 60110014000 | SPACER BUSH. SPR. SUPP. IN. 06 | | 1.00 |
| 13* | 0625060060 | BALL BEARING 6006 DDU2CG23S6NM | | 2.00 |
| 14* | 60110016000 | NILOS RING 6006AV | | 1.00 |
| 15* | 60110012000 | SPACER BUSH. SPROCKET SUPP. 06 | | 1.00 |

| | | | | |
|----|-------------|--------------------------------|-----------------|------|
| 16 | 61010059000 | DAMPING RUBBER 05 | | 5.00 |
| 17 | 61010051138 | REAR SPROCKET 38-T STEEL 05 | | 1.00 |
| 17 | 61010051139 | REAR SPROCKET 39-T STEEL 05 | | 0.00 |
| 17 | 61010051140 | REAR SPROCKET 40-T STEEL 05 | | 0.00 |
| 18 | 61010056000 | BOLT FOR SPROCKET SUPPORT 05 | | 5.00 |
| 19 | 61010057000 | NUT REAR SPROCKET 05 | | 5.00 |
| 20 | 61010060000 | BRAKE DISK REAR D=240MM 05 | | 1.00 |
| 21 | 61009062018 | SPECIAL SCREW M8X18 05 | | 5.00 |
| 22 | 60010081044 | WHEEL SPINDLE REAR CPL. 03 | | 1.00 |
| 23 | 60010084000 | Chain tension adjuster, right, | | 1.00 |
| 24 | 61010086000 | Collar nut M25X1.5 WS=32 05 | | 1.00 |
| 25 | 50304040100 | screw M10x1.25x50 WS10 | | 2.00 |
| 26 | 58414030000 | HH COLLAR NUT M10X1,25 WS=13 | MINI ADV. | 2.00 |
| 27 | 60010165118 | CHAIN 525 WITH MASTER LINK 03 | NEED RIVET TOOL | 1.00 |
| 28 | 60010066000 | MASTER LINK FOR CHAIN 525 03 | NEED RIVET TOOL | 0.00 |
| 31 | 58709076000 | VALVE CPL. BREMBO DUKE 2003 | | 1.00 |
| 98 | 00050002011 | DRIVETRAIN KIT SD/SDR 17T/38T | | 0.00 |
| 99 | 61010015000 | REAR WHEEL REP. KIT | | 0.00 |

* = New part