



Pos	Part Number	Description	Additional Text	Quantity
1	60040001000	E-STARTER ENGINE CPL. LC8-E 03		1.00
2	0015060253	HH COLLAR SCREW M 6X25 WS=8		2.00
3	0770335030	O-RING 33,5X3 VITON		1.00
4	0625160011	GROOV.BALL BEAR. 16001 JRX C3		2.00
5	60040015000	DOUBLE GEAR W.CPL.49-T/10-T 03		1.00
6	0471170010	CIRCLIP DIN0471-17X1		1.00
7	50333041000	STOP DISC 17,2X26X1 B		1.00
8	60040022119	IDLER GEAR 19-T 03		1.00
9	0405172110	NEEDLE BEARING K 17X21X10		1.00
10	60040023000	BEARING BOLT 17X33 03		1.00
11	0618253220	NEEDLE BUSH HK2520 25/32/20 02		1.00
12	60040022023	IDLER GEAR 2 23-T 03		1.00
14	60040020000	FREEWHEEL GEAR WH. 57-T CPL.03		1.00
15	60040027050	SUPPORTING SLEEVE 03		2.00
16	60040027000	FREEWHEEL HOLDER 03		1.00
17	0015060253	HH COLLAR SCREW M 6X25 WS=8		2.00
18	60039005100	IGNITION ROTOR 04	INCL. FREEWHEEL	1.00
20	0984060166	AH SCREW DIN6912 M6X16 10.9		6.00

21	0603061001	CU-SEAL RING DIN7603-6X10X1		1.00
22	0015060163	HH COLLAR SCREW M 6X16 WS=8	FE, FS	1.00
23	0985060003	Self lock. nut DIN985-M6-A2		1.00
24	0125060003	WASHER DIN0125-A 6,4		1.00