

10	61007025000	BRACKET FUEL TANK 05		2.00
11	61007027000	RUBBER BEARING FUEL TANK 05		2.00
12	61007026000	SPECIAL SCREW M10X36 AH 05		2.00
13	61007065000	collar bushing, front tank hol		2.00
14	61007060000	collar bushing, bearing, outsi		1.00
15	0912080403	AH collar screw DIN0912 M8x40		1.00
16	60007008051	SEAL. FLANGE F.TANK INSERT 03		1.00
17	60007008150	TANK INSERT 05		1.00
18	60007008052	SEAL. RING F. TANK INSERT 03		1.00
19	61007008000	TANK PLUG CPL. 05		1.00
20	0912050083	SHCS DIN 912 M5x8		3.00
21	0912050123	AH SCREW DIN0912-M 5X12		1.00
22	0912050303	AH SCREW DIN0912-M 5X30		3.00
25	60007024000	CONNECT.PIECE F.OVERFLOW M7 03		2.00
26	60007024050	GASKET FOR CONNECTING PIECE 03		2.00
27	60007026001	HOSE NBR 5,4X9,4 PER METER	ONLY FOR USA	0.00
30*	58207080200	GAS LEVEL SENSOR 07		1.00
31	0912050163	AH collar screw DIN 912 M5x16		2.00
32	61011094000	CABLE TIE WITH PLUG M6		2.00
40*	6110805000074A	SPOILER LEFT ORANGE 07	WITH DECAL	1.00
41*	6110805100074A	SPOILER RIGHT ORANGE 07	WITH DECAL	1.00
42	60008045000	SPECIAL WASHER D=16,5MM 03		6.00
43	0012060123	AH SCREW DIN6912 M6X12		4.00
44	0014060133	HH COLLAR SCREW M 6X13 WS=8		4.00
45	54603048100	clip nut M6		2.00
46*	61108050050	INNER COVER SPOILER LEFT 07		1.00
47*	61108051050	INNER COVER SPOILER RIGHT 07		1.00
50	0016050121	SCREW FOR PLASTIC 50X12	BLACK	5.00
51	50235033300	SNAP-NUT HOLDER M6 KP142		2.00
52*	6100802014473A	FRONT-END SPOILER CPL. OR. 07	WITH DECAL	1.00
53*	61008020150	THERMAL PROTECTION FOIL 07		1.00
54	0012060164	AH SCREW DIN6912 M6X16 SL		2.00
56	0017060203	EJOT PT SCREW K60X20 WS=6	MXC, EXC	2.00
60*	6100704000047	SEAT BLACK LOGO ORANGE 07		1.00
61	61007040010	DISTANCE RUBBER SEAT 05		6.00
62	61007050000	SEAT LOCK 05		1.00
63	61007052000	SPACER RING SEAT LOCK 05		1.00
64	61007050020	SCREW M4 AF32 05		1.00
65	61007050010	WASHER AF150 05		1.00
66	61007050040	CLOSING PANEL TR248 05		1.00
67	61007050050	WASHER TR12.01 05		1.00
68	61007050030	NUT M19 X1 AF36 05		1.00

* = New part