




Pos	Part Number	Description	Additional Text	Quantity
1	75029047000	PRESS. TOOL F. CRANKS. CPL.		1.00
2	75029021000	EXTRACTOR PRIM. CPL.		1.00
3	75029081000	GEAR SEGMENT CPL.		1.00
4	75012001060	SUPPORT CPL.		1.00
5	75012001070	RETAIN. ARM F. ENG.WORK STAND		1.00
6	75029015102	PISTON R. COMPRESSOR DM=102		1.00
7	75029033000	MOUNTING SCREWS		4.00
8	75029035000	PLUG IN FUSE PISTON PIN		1.00
9	75029094000	OIL PRESSURE ADAPTER		1.00
12	75029050000	ON TENSIONER PL. CYLINDER HEAD		1.00

13	75029051000	PRESS OUT PUNCH CPL.		1.00
14	77329060000	INSERT FOR VALVE SPRING LEVER		1.00
15	75029080000	MOUNT.SLEEVE F. SH.S.RING MS		1.00
16	75029080050	MOUNT.SLEEVE F. SH.S.RING KS		1.00
18	75029090000	PROTECTOR CAP F.CRANKSHAFT 07		1.00
19	75029091000	HOLDING SPANNER FOR FLYWHEEL		1.00
20	77329051000	UNLOCK CHAIN TENSIONER		1.00
21	15112017000	BUSHING EXTRACTOR		1.00
22	15112018100	INTERN.BEAR.PULLER 18-23 MM		1.00
23	56012001000	ASSY SUPPORT (WITHOUT HOLDER)		1.00
24	77329010000	LOCATING SCREW		1.00
25	58429009000	MAGNETO EXTRACTOR		1.00
26	75029172000	SPARK PLUG WRENCH		1.00
27	59029033000	EXTRACTOR FOR TIMING GEAR		1.00
28	58429037043	MOUNTING TOOL F.BEARING NJ 207		1.00
29	59029019000	VALVE SPRING LEVER		1.00
30	59029026006	LIMIT PLUG GAUGE F.VALVE GUIDE		1.00
31	58529005000	MOUNT.SLEEVE F. SH.S.RING WAPU		1.00
32	75029048000	CASING DISMOUNTING TOOL 07		1.00
33	6899785	LOCTITE 243 BLUE 5 ML		1.00
34	58429059000	LOCTITE 648 GREEN 10ML		1.00
35	58429059200	LOCTITE 5910 50ML		1.00
37	75029047050	PRESS OUT PLATE TOP PART		1.00
38	75029047051	PRESS OUT PLATE BOTTOM PART		1.00