



LOCTITE 243

Pos	Part Number	Description	Additional Text	Quantity
1	76211000000	BATTERY BOX		1.00
2	76211000070	SPACER PIN BATTERY BOX		2.00
3	76211000050	HOLDER FOR BATTERY		1.00
4	0024060106	HH COLLAR SCREW M6X10 TX30		9.00
5	43205062100	silentbloc 20x15-M6x10-(1)	ONLY FOR USA	4.00
6	0985060003	Self lock. nut DIN985-M6-A2		4.00
7	59003001099	METAMOLL 90X45X3MM 03		4.00
8	76239031000	CDI DIGITAL BOX		1.00

9	58439030200	RUBBER BRACKET FOR DIGI-BOX 03	1.00
10	58439030250	SUPPORT FOR RUBBER BRACKET 03	1.00
11	0991060103	FLAT HEAD SCREW DIN7991 M6X10	2.00
12	76211058000	Starter relay	1.00
13	58011109130	Plug-in fuse, big 30A	2.00
15	0902060083	Oval head screw ISO 7380 M 6X8	3.00
16	58411057000	STARTER RELAY '96	2.00
17	0985050103	OVAL HEAD SCR. DIN7985-M 5X10	2.00
18	58411053100	BATTERY 12V 8,6AH 03	1.00
19	0934060003	Hex. nut DIN 934 M6	2.00
20	0025060106	HH collar screw M6x10 TX30	2.00
21	76211086000	BATTERY CABLE 07	1.00
22	76211059000	STARTER CABLE	1.00
23	76211097000	GROUND CABLE	1.00
24	58411097100	GROUND CABLE D=6MM L=140MM '97	1.00