



16	75011088010	FUSE 10A 07		0.00
16	75011088015	FUSE 15A 07		0.00
16	75011088020	FUSE MINI 20A		0.00
16	75011088030	FUSE 30A		0.00
19	90611157000	RELAY (AUX1DIODE)		1.00
20	90611053000	BATTERY 12V/8AH		1.00
21	90211197000	EARTH CABLE		1.00
22	90211059000	CABLE RELAY TO MOTOR		1.00
23	90111058000	STARTER RELAY		1.00
24	90111054000	BRACKET RUBBER FOR BATTERY		1.00
26	J025060109	HH-COLLAR SCREW M6X10 SW8		2.00
27	90611054000	BRACKET BATTERY MTG		1.00
28	J025060103	HH COLLAR SCREW M6X10 SW10		1.00
29	90103001051	HOLDING PLATE FLASHER RELAY		1.00
30	90808073000	SPECIAL SCREW M6X1X10		1.00
31	90511030000	indicator relay		1.00
32	90911021000	CONTROL UNIT HEAD LIGHT		1.00
33	90111040000	CAN TERMINATION UNIT		1.00