




Pos	Part Number	Description	Additional Text	Quantity
5	59411075000	WIRING HAR. 250-525 EU+AUS 05		1.00
7	44611207200	FLASHER UNIT 97		1.00
13	54811083100	SUPPORT BRACKET EXC 2005		1.00
15	57013070100	PVC-CLAMP 7,9 MM HEYCO 3355		1.00
16	0015060303	HH COLLAR SCREW M 6X30 SW=8	LC4, LC4 SM, DUKE	2.00
17	58314060050	spacer bushing for speedometer		2.00
31	58211031100	BRACKET FOR FLASHER RELAY		1.00
34	80011034000	VOLTAGE REGULATOR 04	300 EXC USA	1.00
36	44011076200	Cable tie 200/4.6mm black		0.00
36	44011076305	CABLE TIE 300/4,8MM BLACK		0.00
40	58011109110	Plug-in fuse, big 10A		2.00
42	57013072000	WIRING HOLDER 12MM		0.00
42	57013072100	WIRING HOLDER 16MM		0.00
43	58111076000	CABLE SUPPORT KHS NR.150-47610		2.00
45	49111425000	BULB 12V 1,2W (W2X4,6D)		2.00
53	58511053000	BATTERY 12V 4AH YTX5L-BS		1.00
54	50303018000	RUBBER L=145MM		2.00

55	59011055100	BATTERY CARRIER PLAST.BLACK 05		1.00
56	58711086000	WIRING HARNESS BATTERY DUKE'99		1.00
58	58211058000	Starter reley 12V 99		1.00
59	58411059100	STARTERCABLE 700 MM '97	STARTERRELAIS- STARTERENGINE	1.00
60	50311060000	DC HORN 12V K80/L LEB		1.00
61	59011061000	BRACKET 2001		1.00
63	54603048100	clip nut M6		1.00
67	58411097100	GROUND CABLE D=6MM L=140MM '97		1.00
68	58411098100	CONTACT WASHER M6 VSV-K6		1.00
69	58440099000	PROTECTION CAP F. STARTER ENG.		1.00
73	0985060003	Self lock. nut DIN985-M6-A2		1.00
80	59011080100	FLASH. WIRINGHARNESS FRONT 06		1.00
81	59011081100	FLASH. WIRINGHARNESS REAR 06		1.00
86	0912050083	SHCS DIN 912 M5x8		1.00
88	0902060083	Oval head screw ISO 7380 M 6X8		2.00
90	0014060103	HH COLLAR SCREW M 6X10 WS=8		2.00
91	0014060153	HH COLLAR SCREW M 6X15 WS=8		1.00
93	0015060123	HH COLLAR SCREW M 6X12 WS=8		1.00
96	0017060203	EJOT PT SCREW K60X20 WS=6	MXC, EXC	3.00