




Pos	Part Number	Description	Additional Text	Quantity
1*	51509001044	FRONT WHEEL CPL.6X21"EXCEL XC		1.00
2	78009010144	FRONT WHEEL HUB CPL.		1.00
3	54809011000	BEA.SPACERTUBE 35X2 L=79,4 03		1.00
4	0625069068	Grooved ball bearing 6906		2.00
6	0760354771	Radial shaft seal 35X47X7 TC		2.00
8	78009012000	SPACER BUSHING F. FR. WHEEL 08		2.00
10*	77109071226	SPOKE M4,5x226-21" 11		36.00
11*	77109072000	Spoke nipple M4.5 AL		36.00
12*	51509070000	RIM FRONT 1,6"X21" EXCEL AL7		1.00
13	50309073000	Tube protector 21"		1.00
15	78009015000	FRONT WHEEL REP. KIT		0.00
16	51009100100	RIM LOCK VM1 (1,60")	ONLY FOR 19" WHEEL	1.00
17	50310090050	NUT FOR WHEEL HOLDER '96		1.00

20	77309060000	BRAKE DISC FRONT 260		1.00
21	59009062013	SPECIAL SCREW M6X13 WS=8 10.9		6.00
30	77309081000	Wheel spin. front D26 M24x1.5		1.00
32	54809082000	SPINDLE SCREW M24X1,5 WS=27 03		1.00
33	54809081050	PLUG BUSHING WS=27 03		1.00
38	55003135000	PLUG FOR RIM		0.00
40	54809081070	AUXILIARY SCREW FRONT 06		1.00
99	00050000916	SPOKE KIT FRONT "21"		0.00

* = New part