



Pos	Part Number	Description	Additional Text	Quantity
1	76511059000	STARTER-CABLE L=570MM 08		1.00
2	75011059150	BATTERY-CABLE L=170MM		1.00
3	76211097000	GROUND CABLE		1.00
4*	27011056044	Retaining bracket		1.00
5	58411053100	BATTERY 12V 8,6AH 03		1.00
6	58411097100	GROUND CABLE D=6MM L=140MM '97		1.00
7	58211058000	Starter relay 12V 99		1.00
8	58011109130	Plug-in fuse, big 30A		2.00
8	58011109125	FUSE 25 A		1.00
8	58011109115	FUSE 15 A		0.00
9*	76511054100	BATTERY BRACKET		1.00

10*	61111057000	RELAY CM1A-R-12V-H80 07		4.00
11	0025050126	HH collar screw M5x12 TX30		3.00
12	76511055000	HOLDER F.ELECTRIC 08		1.00
13	43205062100	silentbloc 20x15-M6x10-(1)	ONLY FOR USA	3.00
14	0024060106	HH COLLAR SCREW M6X10 TX30		3.00
15	0902060083	Oval head screw ISO 7380 M 6X8		2.00
16	0912050083	SHCS DIN 912 M5x8		2.00
17*	61341031300	Control unit EFI		1.00
19*	27011056050	absorber f. battery retaining		1.00
20*	0025050106	HH collar screw M5x10 TX30		1.00
21	62111059060	COVER POSITIVE POLE		1.00
22	12011016000	WASHER 6 X 12 X 3		2.00
23	0025060126	HH collar screw M6x12 TX30		2.00
24	0025060166	HH collar screw M6x16 TX30		2.00
25	0934060003	Hex. nut DIN 934 M6		2.00
26	0024060136	HH collar screw M6x13 TX30		2.00
27	76511059061	RETAINING PLATE STARTER CABLE		1.00
28	58411098100	CONTACT WASHER M6 VSV-K6		2.00
29	0025060206	HH collar screw M6x20 TX30		1.00
30*	60342090100	inertial sensor		1.00
31*	62142041000	DAMP. COMPONENT ABS MODUL		3.00
32*	61342041000	Collar bushing 6.5X9X18X8.5		3.00
33*	76903001061	Retaining bracket, angle senso		1.00
34*	0024060256	HH COLLAR SCREW M6X25 TX30		2.00
35	58211058050	BRACKET RUBBER F.STARTRELAY 07		1.00
36	60341031050	ECU RUBBER BRACKET		1.00
37	75011087050	RUBBER CASING FOR FUSE BOX		1.00

* = New part