



Pos	Part Number	Description	Additional Text	Quantity
1	93311075000	Main wiring harness		1.00
2	93011060100	Horn		1.00
3	J025080123	HH COLLAR SCREW M8X12 SW12		1.00
4	93541088000	rollover sensor		1.00
5	J025060169	HH COLLAR SCREW M6X16 SW8		2.00
6	93811043000	resistor		1.00
7	93539010000	Start OK control unit		1.00
8	90511030000	indicator relay		1.00
9	93011034000	Voltage regulator		1.00
10	J025060253	bolt flanged M6X25		2.00
11	93041080050	Cable		1.00
12	93011059000	Starter cable 6MM		1.00
13	93011197000	Ground wire		1.00

14	90111058000	STARTER RELAY		1.00
15	93011055060	Band batterie		1.00
16	93011055000	Battery rubber holder		1.00
17	93011054000	BOX BATTERY		1.00
18	93008018060	Cross brace cover		1.00
19	90611053000	BATTERY 12V/8AH		1.00
20	75011088010	FUSE 10A 07		8.00
21	75011088015	FUSE 15A 07		3.00
22	75011088030	FUSE 30A		2.00
23	J005050123	FLAT HEAD SCREW M5X12 PH		3.00
24	90108050001	CLIP NUT M5		3.00
25	93038091000	Pigtail oil pressure switch		1.00
26	93011056100	Bracket battery band		1.00
27	90611057000	relay (interlock)		4.00
28	93011026000	protector		1.00
29	93511084000	PIGTAIL PH-3 FUEL PUMP		1.00
30	93008078000	Rubber grommet		2.00
31	93042033000	Cable earth ABS		1.00
31	93811099000	wiring harness temperatur sens		1.00
32	J025060122	Hex collar screw M6X12		2.00
33	J125050008	Washer M5		1.00
34	J912050166	bolt socket-M5X0.8XL16XCL8.8XB		1.00