



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|---------------|-------------------------|-----------------|----------|
| 1 | 93830002033 | Ignition cover cpl. | | 1.00 |
| 2 | 93830040000 | Ignition cover gasket | | 1.00 |
| 3 | 94245051033 | STATOR ASSEMBLY | | 1.00 |
| 4 | 90839005000 | ROTOR CPL. | | 1.00 |
| 5 | J900001800700 | cap tdc finder | | 1.00 |
| 6 | J770015824 | O-RING 15,8X2,4 | | 1.00 |
| 7 | 90130024000 | PIN DOWEL 8X6,4X14MM | | 2.00 |
| 8 | J025050081 | Hex collar screw M5X8 | | 5.00 |
| 9 | 90230062000 | BRACKET HARNESS MAGNETO | | 1.00 |

| | | | |
|----|-------------|--------------------------------|-------|
| 11 | 90239090001 | RUBBER GASKET SPARK PLUG | 1.00 |
| 12 | 93839091000 | Sealing boot spark plug | 1.00 |
| 13 | 90239093000 | SPARK PLUG M12X1,25 | 1.00 |
| 14 | 90230060002 | front sprocket cover | 1.00 |
| 15 | J025060506 | Hex collar screw M6X50 | 3.00 |
| 16 | J025060353 | Hex collar screw M6X35 | 12.00 |
| 17 | J770024015 | O-RING 24X2,5 | 1.00 |
| 18 | 90230094000 | PLUG SCREW M24X1,5 | 1.00 |
| 19 | 90240018000 | BUSH STARTER SHAFT | 2.00 |
| 20 | 90230066300 | OIL NOZZLE | 1.00 |
| 21 | 90239005050 | ROTOR SCREW CPL. | 1.00 |
| 22 | 93003082000 | Bolt socket M6X1XL22 BLK stepe | 1.00 |
| 23 | J912050353S | AH SCREW M5X35 SELF LOCKING | 3.00 |
| 24 | 90230058000 | PLATE HARNESS MAGNETO | 1.00 |
| 25 | 93730059000 | PLATE HARNESS 2 | 1.00 |
| 26 | 90130001001 | SOCKET HEAD SCREW M6X20 | 4.00 |
| 27 | J797060003 | TOOTHED WASHER M6 | 4.00 |
| 28 | J028060164 | BOLT FLANGE M6X16 | 1.00 |
| 29 | 90240020002 | RETAINER GEAR STARTER | 1.00 |
| 30 | J912060353 | Hexagon screw M6X35 | 2.00 |
| 31 | 90130001000 | SUPPORT FREEWHEEL CLUTCH | 1.00 |
| 32 | 90140026000 | FREEWHEEL CLUTCH | 1.00 |
| 33 | 93039010000 | cover ingition coil | 1.00 |
| 34 | 93039011000 | sleeve cover ignition coil | 2.00 |
| 35 | 93003081000 | Distance bushing sprocket cove | 1.00 |
| 36 | 93339006033 | Ignision coil cmpl. | 1.00 |