



Pos	Part Number	Description	Additional Text	Quantity
1	54632095000	needle sleeve HK 1412 14x20x12		2.00
2	61434005044	SHIFT SHAFT CPL.		1.00
4	56534013100	TENSIONING SPRING 0,8MM		1.00
6	0760142460	radial shaft seal 14x24x6 B		1.00
7	61434014000	RETURN SPRING 2.3 MM		1.00
8	54634020000	SPRING GUIDE		1.00
9	54634050000	STOP DISK 14X30X1	EXHAUST	1.00
10	58038023200	PRESSURE SPRING 0,9MM		4.00
11	59034020000	SHIFT RAIL 11,8X105MM		2.00
12	50334018100	SHIFTING ROLLER 6X8X5,2		3.00
13	61734002000	Shift fork 2/3 gear		1.00
14	61734001000	Shift fork 1/4 gear		1.00

15	0024060206S	HH collar screw M6x20 TX30		1.00
16	61434024000	LOCKING LEVER CPL.		1.00
17	75034052000	SLEEVE FOR LOCKING LEVER 07		1.00
18	61234023000	SPRING - LOCKING LEVER		1.00
19	0912060309S	Hexagon socket screw, DIN0912-		1.00
20	61434015000	SHIFT LOCATING DRUM CPL.		1.00
21	0625618050	BALL BEARING 61805 C3		1.00
22	61734003000	Shift fork 5/6 gear		1.00
23	0625068080	GROOVED BALL BEARING 6808 JRC3		1.00
24	61734012001	Selector drum 6 gear		1.00
25	79234012020	Magnet bracket cmpl.		1.00
26	61434050000	MAGNET HOLDER		1.00
28	0984050143S	CYL. SCREW DIN6912 M5X14 8.8		2.00
29	60411023000	GEAR POSITION SENSOR		1.00
30	61734031033C1	Gear shift lever cmpl.		1.00
33	0738060185	Round head scr. ISR M6x18-A2-7		1.00
34	61734032000C1	Gear shift lever, foot peg		1.00
35	61734035000	Rubber Step Shiftlever		1.00
36	0035080156S	AH-COLLAR SCREW M8X15 TORX45		1.00
37	61334036044	Shift rod cmpl.		1.00
38	0738060225S	Oval head screw ISR M6x22-A2-7		1.00
39	61703038060C1	Spacer bushing		1.00
40	61734030000C1	Gear linkage		1.00
41	0738060205S	Oval head screw ISR M6x20-A2-7		1.00
42	50233041500	PAIR NORDLOCK WASHER M6		1.00
43	0024060206S	HH collar screw M6x20 TX30		1.00