



Pos	Part Number	Description	Additional Text	Quantity
1	61703001100EB	Frame 617TA		1.00
2	61703005000C1	Engine hanger front left		1.00
3	61703006000C1	Engine hanger front right		1.00
4	61703007000C1	Engine hanger rear left		1.00
5	61703008000C1	Engine hanger rear right		1.00
6	0035100249S	HH collar screw M10x24 ISA45 S		14.00
7	61711064000	One-way screw 617		2.00
8	54603048100	clip nut M6		4.00
9	69008021080	clip nut M5		1.00
10	61342046000	Support ABS-pipe d7.5		1.00
11	0025060106	HH collar screw M6x10 TX30		1.00
12	58411098100	CONTACT WASHER M6 VSV-K6		2.00

13	0025060166	HH collar screw M6x16 TX30	2.00
14	61703038000C1	Front footpeg bracket left	1.00
15	61703040000C1	Front footpeg left	1.00
16	0035080206S	SHCS M8x20 TX45	12.00
17	61703043000	Footpeg bolt	2.00
18	61703042000	Spring footrest front	2.00
19	61703039000C1	Front footpeg bracket right	1.00
20	61703041000C1	Front footpeg right	1.00
21	61703045010	Footrest bottom fixing nut	2.00
22	6170300202056	Subframe right	1.00
23	61703002030C1	Fuel tank bridge	1.00
24	61703048000C1	Rear footpeg bracket left	1.00
25	61703049000C1	Rear footpeg bracket right	1.00
26	61703050033C1	Rear footpeg left compl.	1.00
27	61703053000	Rear foot peg bolt	2.00
28	61703051033C1	Rear footpeg right compl.	1.00
29	69013099150	Screw, reservoir	5.00
30	6170300201056	Subframe left	1.00
31	0035080356S	SCREW M8X35 ISA45 SS	2.00
32	0035080606S	Hex screw w.intern.Torx w.coll	2.00
33	6170300205456	Fastening plate top left	1.00
34	6170300205556	Fastening plate top right	1.00
35	6170300204056	Cross brace, rear part	1.00
36	0025050106	HH collar screw M5x10 TX30	2.00
37	0035080256S	ISA collar screw M8x25 ISA45	2.00
38	61707048170	Tether, passenger	1.00
39	61703002060	Edge protection	1.00
42	61703288000	Plug small	2.00
43	61703188000	Plug, small	8.00
44	61703088000	Plug, large	2.00
45	61711065000	Spacing tube ignition lock	2.00