



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|-------------|--------------------------------|----------------------------|----------|
| 1 | 309098 | SILICON GASKET THREE-BOND | | 1.00 |
| 2 | 0113080802 | ENGINE BLOCKING SCREW | | 1.00 |
| 3 | 15112017000 | BUSHING EXTRACTOR | | 1.00 |
| 4 | 45129075000 | REVMETER | | 1.00 |
| 5 | 50329050000 | VENT INJEKTION HYDR. CLUTCH | | 1.00 |
| 6 | 56012001000 | ASSY SUPPORT (WITHOUT HOLDER) | | 1.00 |
| 7 | 58429059000 | LOCTITE 648 GREEN 10ML | | 1.00 |
| 8 | 58529005000 | MOUNT.SLEEVE F. SH.S.RING WAPU | | 1.00 |
| 9 | 59029019000 | VALVE SPRING LEVER | | 1.00 |
| 10 | 59029021044 | EXTRACTOR PRIM. GEAR CPL. | WITH M4, M5, M6, SCREWS | 1.00 |

| | | | | |
|----|-------------|--------------------------------|---------|------|
| 11 | 59029026006 | LIMIT PLUG GAUGE F.VALVE GUIDE | | 1.00 |
| 12 | 59029041000 | FEELER GAUGE SET10,12,15,20,25 | | 1.00 |
| 13 | 6899785 | LOCTITE 243 BLUE 5 ML | | 0.00 |
| 14 | 60029002000 | ENGINE BRACKET FOR LC8 03 | | 0.00 |
| 15 | 60029003000 | BRACKET FOR CLUTCH | | 1.00 |
| 16 | 60029005000 | MOUNT.SLEEVE F. SH. SEAL RING | | 1.00 |
| 17 | 60029006000 | ADAPTOR F.OIL PRESSURE GAUGE | | 1.00 |
| 18 | 60029009000 | FLYWHEEL EXTRACTOR | | 1.00 |
| 19 | 60029009010 | PUSH SCREW F. FLYWH. EXTRACTOR | | 1.00 |
| 19 | 60029009110 | PUSH SCREW F. FLYWH. EXTRACTOR | M16X1,5 | 1.00 |
| 20 | 60029010000 | DEGREE DISK 360DEG - 1/2 INCH | | 1.00 |
| 21 | 60029011000 | SYNCHRONIZER CPL. 2-CYLINDER | | 1.00 |
| 22 | 60029012000 | PLASTIGAUGE - MEASURING STRIP | | 1.00 |
| 23 | 60029015000 | PISTON RING COMPRESSOR CPL. 03 | | 1.00 |
| 24 | 60029016000 | SETTING GAGE F. FLOAT LEVEL | | 1.00 |
| 25 | 60029018000 | INTERN.BEAR.PULLER 28 MM | | 1.00 |
| 26 | 60029031000 | PRESSURE PUNCH F. CRANKSHAFT | | 1.00 |
| 27 | 60029033000 | EXTRACTOR PRIM. GEAR | | 1.00 |
| 28 | 60029041000 | INSERT FOR VALVE SPRING LEVER | | 1.00 |
| 29 | 60029043010 | SEAL.RING PRESS PUNCH PUSH ROD | | 1.00 |
| 30 | 60029043020 | SEAL.RING PRESS PUNCH COUNT.SH | | 1.00 |
| 31 | 60029043030 | PRESS PUNCH SEAL.RING/BEARING | | 1.00 |
| 32 | 60029043040 | SEAL.RING PRESS PUNCH WAT.PUMP | | 1.00 |
| 33 | 60029043050 | SEAL.RING PRESS PUNCH BA.SHAFT | | 1.00 |
| 33 | 60029043060 | PRESS PUNCH WAPU-BEARING | | 1.00 |
| 34 | 60029044050 | PRESS TOOL FOR MAIN BEARING | | 1.00 |
| 35 | 60029046028 | PRESS TOOL F. SUPPORT BEARING | | 1.00 |
| 36 | 60029050000 | BOTTOM PART PRETENSIONING TOOL | | 1.00 |
| 37 | 60029051000 | HOOK WRENCH PRETENS.TOOL CPL. | | 1.00 |
| 38 | 60029058000 | SCISSOR GEAR PULLER | | 1.00 |
| 39 | 60029073000 | SPARK PLUG WRENCH 16MM 1/2INCH | | 1.00 |
| 40 | 60029075000 | SPECIAL SOCKET F.CYL.-HEAD NUT | | 1.00 |
| 41 | 60029081000 | WRENCH FOR CYLINDER-HEAD SCREW | | 1.00 |
| 42 | 60029082000 | HOLDER FOR WATER PUMP WHEEL | | 1.00 |
| 43 | 60029083000 | SPECIAL SOCKET F. CYLINDER NUT | | 1.00 |
| 44 | 61029094000 | EFI PRESSURE TESTER | | 1.00 |
| 45 | 62529093000 | IGNITIONWIRE ADAPTOR | | 1.00 |
| 46 | 75029035000 | PLUG IN FUSE PISTON PIN | | 1.00 |