



Pos	Part Number	Description	Additional Text	Quantity
1	61709A04044	front wheel cpl. 3,5x17 "Brabu		1.00
2	0760354771	Radial shaft seal 35X47X7 TC		2.00
3	0472047175	CIRCLIP DIN0472-47X1,75		1.00
4	0625069068	Grooved ball bearing 6906		2.00
5	61009011000	Bearing spacing tube, front		1.00
6	61009012000	SPACER BUSH. FR. WHEEL L/S 05		1.00
7	60009013000	Spacer bush. fr. whee R/S 03		1.00
8	61912033060	Angle valve 8.3 mm for TPMS		1.00

9	61912033000	Tire pressure sensor		1.00
10	0900000501500S	Screw M5x15 for TPMS		1.00
11	6130906000033	BRAKE DISK D=320/5		2.00
12	76009062000	Special screw M8X25 SL TX40		10.00
13	76042020000	Phonic wheel, front		1.00
14	61009081200	Wheel spindle, front wheel		1.00
15	61009082000	AH screw M25X1.5 WS=12 05		1.00
16	76042125000	ABS-SENSOR		1.00
17	59009062013	SPECIAL SCREW M6X13 WS=8 10.9		1.00
99	61009015000	FRONT WHEEL REP. KIT		0.00