



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|--------------|--------------------------------|-----------------|----------|
| 1 | A46034005033 | Shift shaft cpl. | | 1.00 |
| 3 | 56534013100 | TENSIONING SPRING 0,8MM | | 1.00 |
| 4 | 54634020000 | SPRING GUIDE | | 1.00 |
| 5 | 54834014000 | RETURN SPRING 03 | | 1.00 |
| 6 | 54634050000 | STOP DISK 14X30X1 | EXHAUST | 1.00 |
| 7 | 54632095000 | needle sleeve HK 1412 14x20x12 | | 2.00 |
| 8 | 0760142460 | radial shaft seal 14x24x6 B | | 1.00 |
| 9 | 79234031100 | Shift lever cpl. | | 1.00 |
| 10 | 50233041500 | PAIR NORDLOCK WASHER M6 | | 1.00 |
| 11 | 0024060156S | HH collar screw M6x15 TX30 | | 1.00 |

| | | | |
|----|---------------|--------------------------------|------|
| 12 | 79034003000 | SHIFTING FORK 1.-3. GEAR | 1.00 |
| 13 | 79034002000 | SHIFTING FORK 2. GEAR | 1.00 |
| 14 | A46034019000 | Shift fork shaft (L=93 mm) | 1.00 |
| 15 | 0402061480 | NEEDLE ROLLER DIN5402 6X14,8 | 3.00 |
| 16 | 0025060306S | HH collar screw M6x30 TX30 | 1.00 |
| 17 | A46034015000 | Shift star compl. | 1.00 |
| 18 | 0410002500700 | Grooved ball bearing 6805 JR C | 1.00 |
| 19 | A46034012000 | Shift drum 5 gear | 1.00 |
| 20 | 79234012010 | FRICITION BEARING CONTROLLER | 1.00 |
| 21 | 79234012020 | Magnet bracket compl. | 1.00 |
| 22 | 79211023000 | gear position sensor | 1.00 |
| 23 | 0025050146S | Hex coll. screw M5x14 ISA30 se | 2.00 |
| 24 | 0025050256S | HH collar screw M5x25 TX30 | 1.00 |
| 25 | 0021050003 | washer DIN 9021 A - 5.3 | 1.00 |
| 26 | A46034024044 | Detent arm compl. | 1.00 |
| 27 | 54634052300 | SLEEVE FOR LOCKING LEVER | 1.00 |
| 28 | 54834023000 | LOCKING LEVER SPRING 03 | 1.00 |
| 29 | A46034020000 | Shift fork shaft (L=66 mm) | 1.00 |
| 30 | 79034001000 | SHIFTING FORK 4.-5. GEAR | 1.00 |
| 31 | A46011024000 | Shield gear position sensor | 1.00 |
| 32 | 58038023400 | Compression spring L=25mm D=0. | 4.00 |