




Pos	Part Number	Description	Additional Text	Quantity
1	61229001000	UNIVERSAL MOUNTING RACK		1.00
2	61229002000	ENGINE BRACKET		1.00
3	61229003000	CLUTCH HOLDER		1.00
4	61229005000	MOUNT. SLEEVE SHAFT SEAL RING		1.00
5	61229044000	PRESSING TOOL D53 MAIN BEARING		1.00
6	61229045000	BEARING RING F. PRESSING TOOL		1.00
7	61229010000	PULLER CPL. F. IGNITION COVER		1.00
8	61229020000	RING F. COMB. SHAFT BEARING		1.00
9	61229013000	ARBOR PRESS SS-RING DRIVE		1.00
10	61229015000	ENGINE BLOCKING SCREW		1.00

11	61229016000	PRES.SOCKET COUNTERSHAFT DRIVE		1.00
12	61229017000	PULLER F. COUNTERSHAFT DRIVE		1.00
13	61229018000	COMBINATION PRESSURE PAD		1.00
14	61229025000	EXTENSION TORQUE WRENCH		1.00
15	61229021000	UNLOCKING TOOL		1.00
16	61229008000	PRES.PEACE F.ROTOR EXTRACTOR		1.00
17	58429009000	MAGNETO EXTRACTOR		1.00
18	61229050000	FRAME SUPPORT		1.00
19	61229051000	CENTERING PIN		1.00
20	75029035000	PLUG IN FUSE PISTON PIN		1.00