



Pos	Part Number	Description	Additional Text	Quantity
1	62505007100	EXHAUST PIPE FRONT 05		1.00
2	62505008000	EXHAUST PIPE REAR 05		1.00
3	60005005000	GASKET 03		2.00
4	61005009000	SPACER BUSH. 8,5X15X7,5 05		2.00
5	51010086100	self-locking nut M8 Cu		5.00
6	09081000000	PLUG DIN0908-M10X1 A2		2.00
7	0603100141	sealing ring DIN 7603 10x14x1	ONLY FOR LC4 ADVENTURE	2.00

10	61005007049	CLAMP EXHAUST PIPE 05		1.00
11*	0025080356	HH collar screw M8x35 TX40		2.00
12	0125080003	washer DIN 125 A -8.4		1.00
13	51005067000	INSOLATE WASHER 8,5X28X3		1.00
14	58405050065	collar bushing 8.5x12x23.5x10		2.00
15	62505015150	EXHAUST PIPE BRACKET FRONT 07		1.00
16*	0025080406	HH COLLAR SCREW M8X40 TX40		1.00
20	61005051100	CLAMP CPL. D=53,2MM 05		1.00
21	58405005001	Graphite ring 45X50X25		1.00
29	0991080353	FLAT HEAD SCREW DIN7991-M 8X35		2.00
30	61005052000	EXHAUST CLAMP CPL. 05		1.00
31	62505048100	DISTRIBUTOR TUBE 05		1.00
32*	0025080306	HH collar screw M8x30		4.00
33	58303061100	SPECIAL WASHER ALU 8X24 MM ELO		2.00
34	62505069000	SPACER BUSH. 8,5X12X18MM 05		2.00
35	54305068100	damp. component silicone grey		5.00
36*	0025080166	HH COLLAR SCREW M8X16 TX40		6.00
37	62505047000	THERMAL SHIELD 05		1.00
38	58605083010	SCREW TORX M5X10 05		3.00
39	60005005002	EXHAUST GASKET 03		2.00
40*	62605082000	SILENCER L/S 08		1.00
41*	62605083000	SILENCER R/S 08		1.00
42	54308042000	RUBBER BUFFER		2.00
43	60005095000	CLAMP FOR SILENCER CPL. 03		2.00
44	6000508500001S	SILENCER/HANDLE HOLDER L/S 07		1.00
45	6000508600001S	SILENCER/HANDLE HOLDER R/S 07		1.00
46*	0025080256	HH collar screw M8x25		2.00
47	0021080003	WASHER DIN9021-A 8,4		3.00
48	0797050000	TOOTH LOCK WASHER DIN6797-J		3.00

* = New part