




|    |                 |                                |  |      |
|----|-----------------|--------------------------------|--|------|
| 12 | C90707080090    | Gasket fuel level sensor       |  | 1.00 |
| 13 | 014579050166    | Cap hd. screw ISO14579, M5x16- |  | 7.00 |
| 14 | C90707040000    | rider seat cpl.                |  | 1.00 |
| 15 | C90706001021    | Spaxer rubber airbox           |  | 3.00 |
| 16 | C90707040041    | Isolation pad                  |  | 7.00 |
| 17 | C0000250804000S | Collar screw M8x40 ISA40 SS    |  | 2.00 |
| 18 | 0021080003      | WASHER DIN9021-A 8,4           |  | 2.00 |
| 19 | C90707046000    | Rubber seat cowl pad           |  | 2.00 |
| 20 | C90707049000    | Bushing 8.4x12x21.5            |  | 2.00 |
| 21 | 0900000601500S  | Special screw M6x15x5,5-8.8 MK |  | 2.00 |
| 22 | C90707047033    | Passenger seat cmpl.           |  | 1.00 |
| 23 | C90712008000    | Grip handle passenger          |  | 1.00 |
| 24 | 0035080506S     | AH collar screw M8x50 ISA45    |  | 4.00 |
| 25 | C90707012000    | Tank Protection Set Metamoll   |  | 1.00 |
| 26 | C90707013040    | protectionfoil tank set        |  | 1.00 |