



| Pos | Part Number | Description | Additional Text | Quantity |
|-----|----------------|--------------------------------|-----------------|----------|
| 1 | C90707013000CB | Fuel tank steel | | 1.00 |
| 2 | 64107080200 | Fuel lever sensor | | 1.00 |
| 3 | 0912050203 | AH SCREW DIN0912-M 5X20 | | 2.00 |
| 4 | 59007017000 | CLAMP YDNAC 10096F (9,6MM) | | 1.00 |
| 5 | C90715019735 | Hose 6x10 FKM/ECO L 735 | | 1.00 |
| 6 | C90711092000 | CABLE TIE W. SOCKET D=6,5 | | 1.00 |
| 7 | 54603048200 | RANGE CHANGE METAL NUT M5 | | 2.00 |
| 8 | 54603048300 | RANGE CHANGE METAL NUT M6 INOX | | 2.00 |
| 9 | C90742041000 | Damper ABS modulator | | 2.00 |
| 10 | 61342041100 | Collar bushing 6,5x9x18x8.5 | | 2.00 |
| 11 | C0000250602000 | HH collar screw M6x20 TX30 | | 2.00 |

| | | | | |
|----|-----------------|--------------------------------|--|------|
| 12 | C90707080090 | Gasket fuel level sensor | | 1.00 |
| 13 | 014579050166 | Cap hd. screw ISO14579, M5x16- | | 7.00 |
| 14 | C90707040000 | rider seat cpl. | | 1.00 |
| 15 | C90706001021 | Spaxer rubber airbox | | 3.00 |
| 16 | C90707040041 | Isolation pad | | 7.00 |
| 17 | C0000250804000S | Collar screw M8x40 ISA40 SS | | 2.00 |
| 18 | 0021080003 | WASHER DIN9021-A 8,4 | | 2.00 |
| 19 | C90707046000 | Rubber seat cowl pad | | 2.00 |
| 20 | C90707049000 | Bushing 8.4x12x21.5 | | 2.00 |
| 21 | 0900000601500S | Special screw M6x15x5,5-8.8 MK | | 2.00 |
| 22 | C90707047033 | Passenger seat cml. | | 1.00 |
| 23 | C90712008000 | Grip handle passenger | | 1.00 |
| 24 | 0035080506S | AH collar screw M8x50 ISA45 | | 4.00 |
| 25 | C90707012000 | Tank Protection Set Metamoll | | 1.00 |
| 26 | C90707013040 | protectionfoil tank set | | 1.00 |