




Pos	Part Number	Description	Additional Text	Quantity
1	95711075000	HARNESS WIRING REAR		1.00
2	95711078000	Wiring harness, mask		1.00
3	95811097000	Earth wire		1.00
6	93041080050	Cable		1.00
7	93038091000	Pigtail oil pressure switch		1.00
8	93511084000	PIGTAIL PH-3 FUEL PUMP		1.00
9	90611057000	relay (interlock)		4.00
10	93011058000	Starter relais		1.00
11	95811058050	Rubber grommet, starter relay		1.00
12	95811042033	Power socket, cmpl.		1.00
13	93541088000	rollover sensor		1.00
14	95811060000	Horn		1.00
15	J025080123	HH COLLAR SCREW M8X12 SW12		1.00
16	J025080123	HH COLLAR SCREW M8X12 SW12		2.00

17	28111096000	Transil unit		1.00
18	90611053000	BATTERY 12V/8AH		1.00
19	95811055010	Rubber grommet		1.00
20	93008084010	Range change metal nut M6		1.00
21	90808073000	SPECIAL SCREW M6X1X10		3.00
22	90511034000	voltage regulator		1.00
23	J025060303	FLANGED BOLT M6X30 WS10		2.00
24	90511030000	indicator relay		1.00
25	95811031000	Relay bracket		1.00
26	90508006001	SOCKET HEAD BOLT M6X12		2.00
27	95811055000	battery holder plate		1.00
28	95811055070	Battery retaining pin top		1.00
29	95811055060	Battery retaining pin		1.00
30	93511088000	Fuse 10a		6.00
31	75011088015	FUSE 15A 07		4.00
32	95811059000	Starter cable		1.00
40	93042033000	Cable earth ABS		1.00